

Chromalox

Garanti: 12 ay
Bu ürüne ait Türkiye içi kapı teslim fiyat ve teslim süresi içeren teklifimizi almak için info@yursat.com.tr e-posta adresine başvuru yapabilir ya da ayrıntılı bilgi için +90 224 240 03 04 numaralı telefonumuzdan bizlere ulaşabilirsiniz.
Chromalox Markası, tedarik süresi için lütfen bizimle iletişime geçiniz.

Firmamız Chromalox Türkiye Distribütörü veya temsilcisi değildir. Firmamız sipariş durumunda, belirtilen ürünlerde sadece Orjinal ve yeni ürün teklifi sunmaktadır. Bu sitede gösterilen Özel marka adları ve ticari markalar ilgili sahiplerinin mülkiyetindedir, talep durumunda kaldırılmaktadır.



Ürün	Açıklama
QPC-CHX	Art-Nr.: 0135-28095 Typ: SCR Control Board
Art-Nr.: 0135-28096	Typ: SCR Failure Board
Art-Nr.: 3193975X	Typ: EFTU/S31
Typ: ARMTO-2E2T2XX 3kW 3Ph 575V	Immersion Heater Art-Nr.: 500541545 QPC-CHX Important NOTE: The requested old voltage of 525V is no longer feasible and has been changed to 575V
QPC-CHX	Art-Nr.: 314659 Typ: 6040-RRR001
ZX11580373	Trunnion Brg Lube Sys Oil Reservoir Immersion Heater, 4.5kW, 525V, 3PH, CHROMALOX
CABLE,HEAT TRACE SRL 5-2CR	3007217
CABLE,HEAT TRACE SRL 8-2CR	11.000,00 PC
CABLE,HEAT TRACE SRL 10-2CR	3007219
CABLE,HEAT TRACE SRP 15-2CT	3007222
129867	Typ: OT-1801 240V1P 1000W HKL
130008	Typ: OT-2401HTS240V1P 1000W
308620	Typ: OSK90246/BT-000-J-3 1/2-24-3-U

308558	Typ: BTA-1/C
308793	Typ: OSTW-J-F/C
308195	Typ: CC ^CABLE CLAP 3
327783	Typ: EXPP-J-20-100/C T/C WIRE
SLT060/60 6KW 440V 3PH DELTA	LT17425R Screwed Immersion Heater Model Type: SLT060/60 6kW 440V 3ph Delta Part No: LT17425R To drawing no: DS9-215-22659
Cabb-1211	FORCED AIR DUCT HEATER 480V 3PH
4436-24810000	THREE PHASE CONTACTOR POWER CONTROL PANEL
214180	TYPE CMX
4235-62410000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
4232-1010000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
063-120517-031	240V, 3 PHASE
063-120517-004	480V, 3 PHASE
Armt-3905t1	IMMERSION HEATER 9PH 480V 3KW
063-120517-038	480V, 3 PHASE
063-120517-033	240V, 3 PHASE
4133-13100	THREE PHASE THREE-LEG ZERO FIRED SCR POWER CONTROL PANEL
4168-63000	4168 MINI SCR PANEL
4236-67210000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
4236-52410000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
Tmo -12-016p-E4 240v 1-	
4432-48010000	THREE PHASE CONTACTOR POWER CONTROL PANEL
4436-62410000	THREE PHASE CONTACTOR POWER CONTROL PANEL
Tmo -03-009p-E2 240v 1-	
Tv47en030-3000w	
Tmo -12-036p-E2 480v 1-	
303375265	HEATER LUH-D-07-43-32-00 480V3P 7.5KW
4235-14810000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
4133-01100	THREE PHASE THREE-LEG ZERO FIRED SCR POWER CONTROL PANEL
4132-07110	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
Tm-36a300e4c37axx,Cs.	500314016 Line Notes : TM-36A300E4C37AXX,CS, 480V, 3PH, 300KW
0135-02261	SSR/GFI POWER CONTROL ASSY., WITH HEAT SINK
4432-38010000	THREE PHASE CONTACTOR POWER CONTROL PANEL
293-587	WEATHER-RESISTANT THERMOSTATS AR-519LT7FT THERMO 200-550 F
296-120971-032	EXPANSION TANK ASSEMBLIES
295814	SDRA-CC-30-93 30KW 600V 3PH

214092	TYPE CMX
4235-47210000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
700111	XPMC-12211T3
4236-34810000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
4235-24810000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
Tmo -03-003p-E1 240v 1-	
700058	XPMC-12111T3
4131-07100	CLASS I, CLASS 1 2, GROUP B, C, D, CLASS 2, DIV 1 2, GROUPS E, F, G.
052-074329-004	IMMERSION HEATER 1PH 480V 3000W
296-123419-006	EXPANSION TANK ASSEMBLIES
0076-12050	FLOOR STAND KIT, 12" DEEP, 304 SS
296-123419-007	EXPANSION TANK ASSEMBLIES
214025	TYPE CMX
4168-33000	4168 MINI SCR PANEL
304127	HEATER 10.3/12AMP 3.7/5KW 3PHASE 240V
Dhxi-Gpa-08hx012wx06.50d-480v11p-001.5kw-2mp-Cswam-Xxxxxxxx	DUCT HEATER 3.1AMP 480V 1.5KW 1PHASE 60HZ
Tmo -12-030p-E4 240v 2-	
4168-31000	4168 MINI SCR PANEL
Tmo -06-012p-E2 240v 1-	
4168-64000	4168 MINI SCR PANEL
219571	HVH-20-43-30 480V 3PH 19.8KW
214130	TYPE CMX
063-120517-008	480V, 3 PHASE
4233-1710000	THREE PHASE THREE-LEG ZERO FIRED SIX SCR POWER CONTROL PANEL
4233-1610000	THREE PHASE THREE-LEG ZERO FIRED SIX SCR POWER CONTROL PANEL
4224-32000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
306037102	
4132-01110	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
4432-52410000	THREE PHASE CONTACTOR POWER CONTROL PANEL
4131-13100	CLASS I, CLASS 1 2, GROUP B, C, D, CLASS 2, DIV 1 2, GROUPS E, F, G.
219643	HVH-30-63-30 600V 3PH 30.0KW
4131-03100	CLASS I, CLASS 1 2, GROUP B, C, D, CLASS 2, DIV 1 2, GROUPS E, F, G.
Tmo -12-016p-E2 240v 1-	
296-120971-037	EXPANSION TANK ASSEMBLIES
Tmo -03-004p-E2 240v 1-	
Tmo -12-020p-E4 240v 2-	

Tmo -12-018p-E4 240v 1-	
Tmo -12-012p-E2 240v 1-	
Tmo -03-004p-E2 480v 1-	
4133-11100	THREE PHASE THREE-LEG ZERO FIRED SCR POWER CONTROL PANEL
4232-0810000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
4236-47210000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
Tmo -03-006p-E1 480v 1-	
214199	TYPE CMX
4235-52410000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
Tmo -12-012p-E4 240v 1-3p	
Tmo -12-018p-E2 240v 1-	
4436-38010000	THREE PHASE CONTACTOR POWER CONTROL PANEL
156-050679-004	PLUG IMMERSION HEATER SCREW
4080	
Tmo -03-003p-E1 480v 1-	
Tmo -12-030p-E2 240v 2-	
81015c	AUTOMATIC BLOWDOWN SYSTEMS FOR CHS-495A THROUGH CHS-630A
4268-32000	THREE PHASE TWO-LEG ZERO FIRED SCR MINI POWER CONTROL PANEL
168-122571-066	2 DIA
4235-44810000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
Tmo -06-025p-E2 480v 1-	
296-120971-009	EXPANSION TANK ASSEMBLIES
4235-27210000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
700234	XPMC-12211T2
4236-64810000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
4133-03100	THREE PHASE THREE-LEG ZERO FIRED SCR POWER CONTROL PANEL
4232-1510000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
4232-1610000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
4432-39610000	THREE PHASE CONTACTOR POWER CONTROL PANEL
219678	HVH-35-63-30 600V 3PH 34.2KW
4233-0610000	THREE PHASE THREE-LEG ZERO FIRED SIX SCR POWER CONTROL PANEL
4436-14810000	THREE PHASE CONTACTOR POWER CONTROL PANEL
168-122571-028	3 DIA
Tmo -03-004p5-E2 240v 1	
156-053551-010	HEATER 3PH 480V 9000W 3ELEMENT

219766	HVH-50-63-30 600V 3PH 51.3KW
063-057588-019	480V, 3 PHASE
4132-13110	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
063-120517-024	480V, 3 PHASE
4235-64810000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
4214-31000	4214 SINGLE PHASE ZERO FIRED SCR POWER CONTROL PANEL
Tmo -06-025p-E1 480v 1-	
4463-40000	MULTI-ZONE CONTACTOR POWER CONTROL PANEL NEMA 4X RATED
500506613	IMMERSION HEATER 480V 7500W
4236-54810000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
296-121087-003	EXPANSION TANK ASSEMBLIES
4214-34000	4214 SINGLE PHASE ZERO FIRED SCR POWER CONTROL PANEL
Hgr-380	CONTACTOR 80AMP 120VAC 3POLES
219580	HVH-20-63-30 600V 3PH 20.1KW
700170	XPMC-12111T2
Tmo-03-003p-E1 240v 1-3	
2104	
214041	TYPE CMX
0002-47557	575 VAC SCR 550-650 AMP UNITS
4477-75000	CLASS I, DIVISION II
303204	LUH-D-07-43-32-00 480V3P 7.5KW
4235-34810000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
4436-29610000	THREE PHASE CONTACTOR POWER CONTROL PANEL
Tmo -03-006p-E2 240v 1-	
4432-32410000	THREE PHASE CONTACTOR POWER CONTROL PANEL
Tmo -12-016p-E2 480v 1-	
Tmo -12-020p-E4 480v 1-	
700218	XPMC-6221T2
4436-42410000	THREE PHASE CONTACTOR POWER CONTROL PANEL
4233-1410000	THREE PHASE THREE-LEG ZERO FIRED SIX SCR POWER CONTROL PANEL
F2336-2a	
063-120517-032	480V, 3 PHASE
063-057588-008	240V, 3 PHASE
Tmo -06-015p-E2 240v 1-	
700066	XPMC-12121T3
296-123419-003	EXPANSION TANK ASSEMBLIES

301516	TRMX-H2B 120/240/277V 13.4KW
3380-4rr4100001	CONTROLLER MULTILOOP 100-240VAC 50/60HZ
063-120517-018	480V, 3 PHASE
063-120517-021	240V, 3 PHASE
219598	HVH-25-23-30 208/240V 3PH 18.7/24.9KW
Tmo -03-004p-E1 240v 1-	
4432-62410000	THREE PHASE CONTACTOR POWER CONTROL PANEL
4236-62410000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
295857	SDRA-CC-60-93 60KW 600V 3PH
Srme-20-2ct	
Tmo -03-006p-E2 480v 1-	
155-554735-010	HEATING ELEMENT M 480V 17KW 1-3PH
214084	TYPE CMX
219694	HVH-40-43-30 480V 3PH 37.4KW
168-122571-017	2 DIA
0135-28133	TRIGGER BOARD (200-650 AMP UNITS)
Tmo -06-025p-E1 240v 2-	
063-120517-037	240V, 3 PHASE
219635	HVH-30-43-30 480V 3PH 30.0KW
Tmo -06-012p-E2 480v 1-	
4214-30000	4214 SINGLE PHASE ZERO FIRED SCR POWER CONTROL PANEL
0024-03200	2 X FUSE 500 VAC 1000 AMP (1200 AMP PAK)
Tmo -12-016p-E4 480v 1-	
HtIs-23040	HEAT TRACE CONTROL PANEL DUAL-LOOP 30A 208V NEMA4
214164	TYPE CMX
4236-12410000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
4214-33000	4214 SINGLE PHASE ZERO FIRED SCR POWER CONTROL PANEL
4235-57210000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
296-120971-034	EXPANSION TANK ASSEMBLIES
4168-32000	4168 MINI SCR PANEL
Tmo -03-004p5-E2 480v 1-1	
4232-1210000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
296-123419-005	EXPANSION TANK ASSEMBLIES
Tmo -12-018p-E4 480v 1-	
Tmo -12-030p-E1 240v 2-	
4235-37210000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL

219651	HVH-35-23-30 208/240V 3PH 25.6/34.0KW
214050	TYPE CMX
052074329041	CIRCULATING HEATER 1PH 480V 3000W
063-120517-005	240V, 3 PHASE
306037098	
Tmo-03-006p-E2 480v 1-3	
4236-22410000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
Tmo -06-020p-E2 480v 1-	
063-120517-028	480V, 3 PHASE
214068	TYPE CMX
Tmo -06-020p-E2 480v 1-3p	
063-120517-025	240V, 3 PHASE
Tmo -06-030p-E2 240v 2-	
296-123419-008	EXPANSION TANK ASSEMBLIES
Nwhmt0-3035	CIRCULATING HEATER 1PHASE 480V 3000W
063-120517-023	240V, 3 PHASE
214076	TYPE CMX
4232-0310000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
4236-57210000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
073139-031	UNIVERSAL SUPPORT STANDS
4236-44810000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
4432-19610000	THREE PHASE CONTACTOR POWER CONTROL PANEL
063-120517-016	480V, 3 PHASE
295849	SDRA-CC-60-43 60KW 480V 3PH
063-120517-007	240V, 3 PHASE
Tmo -06-009p-E2 240v 1-	
296-121087-004	EXPANSION TANK ASSEMBLIES
Tmo -12-020p-E2 240v 2-	
Armts-2505/240	IMMERSION HEATER 5KW 240V 1PHASE 19IN
Tmo -12-012p-E4 480v 1-	
Ot-1807 (285 050601 223)	
Tmo -12-030p-E2 480v 1-	
063-057588-002	240V, 3 PHASE
Tmo -12-036p-E2 240v 2-	
063-057588-015	480V, 3 PHASE

341294	THERMEX CORD KIT
296-120971-031	EXPANSION TANK ASSEMBLIES
Tmo -12-024p-E2 480v 1-	
Armts-3455e2t2	IMMERSION HEATER PROCESS WATER APPLICATIONS PLUGIN
Tmo -12-030p-E1 480v 1-	
Tmo-06-030p-E1 Pcn 181868	
4432-22410000	THREE PHASE CONTACTOR POWER CONTROL PANEL
4236-14810000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
4235-17210000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
219686	HVH-40-23-30 208/240V 3PH 28.1/37.4KW
4214-32000	4214 SINGLE PHASE ZERO FIRED SCR POWER CONTROL PANEL
4233-0210000	THREE PHASE THREE-LEG ZERO FIRED SIX SCR POWER CONTROL PANEL
4268-63000	THREE PHASE TWO-LEG ZERO FIRED SCR MINI POWER CONTROL PANEL
Tmo -03-004p5-E2 480v 1	
Nwhmt0-3305	IMMERSION HEATER 1PHASE 480V 3000W
341286	WIRELESS MONITORING KIT FOR PC
S011148y-Kb15	
4224-31000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
063-057588-009	480V, 3 PHASE
4131-05100	CLASS I, CLASS 1 2, GROUP B, C, D, CLASS 2, DIV 1 2, GROUPS E, F, G.
4232-0210000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
Tmo -12-024p-E4 480v 1-3p	
4436-22410000	THREE PHASE CONTACTOR POWER CONTROL PANEL
Tmo -12-030p-E4 480v 1-	
Tmo -03-004p-E1 480v 1-	
4133-07100	THREE PHASE THREE-LEG ZERO FIRED SCR POWER CONTROL PANEL
4436-12410000	THREE PHASE CONTACTOR POWER CONTROL PANEL
4232-0610000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
214148	TYPE CMX
4168-34000	4168 MINI SCR PANEL
219600	HVH-25-43-30 480V 3PH 25.0KW
Tmo -06-015p-E2 480v 1-	
4477-40000	CLASS I, DIVISION II
Tlc-330a-036	IMMERSION HEATER 3000WATT 480V 3PHASE 36IN RISER
4432-29610000	THREE PHASE CONTACTOR POWER CONTROL PANEL
4224-35000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL

306342240	
700090	XPMC-6221T3
4235-22410000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
214033	TYPE CMX
4236-27210000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
700250	XPMC-12425T2
0024-07646	2 X FUSE 575 VAC 1000 AMP (1200 AMP PAK)
S06321a-Kb65	
4432-44810000	THREE PHASE CONTACTOR POWER CONTROL PANEL
Tmo -06-020p-E2 240v 2-	
4235-32410000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
4436-49610000	THREE PHASE CONTACTOR POWER CONTROL PANEL
4132-05110	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
4233-0810000	THREE PHASE THREE-LEG ZERO FIRED SIX SCR POWER CONTROL PANEL
4436-44810000	THREE PHASE CONTACTOR POWER CONTROL PANEL
4268-62000	THREE PHASE TWO-LEG ZERO FIRED SCR MINI POWER CONTROL PANEL
296-121087-005	EXPANSION TANK ASSEMBLIES
063-120517-015	240V, 3 PHASE
296-123419-004	EXPANSION TANK ASSEMBLIES
Lt05105y	
Tmo -03-007p5-E2 480v 1	
4236-32410000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
4235-42410000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
063-071356-058	480V, 3 PHASE
4224-33000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
Tmo -06-008p4-E1 480v 1	
0135-30490	ITLS-DIGITAL CONTROL 10" DISPLAY, PROGRAMMED
219627	HVH-30-23-30 208/240V 3PH 22.4/29.9KW
4436-64810000	THREE PHASE CONTACTOR POWER CONTROL PANEL
A-65-3 Ht Ring 120v 1p 1000w	
329703	
214121	TYPE CMX
4232-1710000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
219715	HVH-45-23-30 208/240V 3PH 33.7/44.8KW
4436-18010000	THREE PHASE CONTACTOR POWER CONTROL PANEL
214105	TYPE CMX

295830	SDRA-CC-48-93 48KW 600V 3PH
296-120971-002	EXPANSION TANK ASSEMBLIES
0135-28135	MAIN + SHORTED SCR + PROPORTIONAL + COVER
Tmo -12-024p-E4 240v 2-	
219660	HVH-35-43-30 480V 3PH 34.0KW
4168-61000	4168 MINI SCR PANEL
4235-67210000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
063-120517-014	480V, 3 PHASE
Tmo -03-003p-E2 480v 1-	
063-120517-034	480V, 3 PHASE
4432-24810000	THREE PHASE CONTACTOR POWER CONTROL PANEL
4168-62000	4168 MINI SCR PANEL
4235-12410000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
81015b	AUTOMATIC BLOWDOWN SYSTEMS FOR CHS-150A THROGUH CHS-420A
063-120517-003	240V, 3 PHASE
Ot-1801	Voltage: 240 volt Power: 1000 watt
4132-11110	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
296-120971-007	EXPANSION TANK ASSEMBLIES
219758	HVH-50-43-30 480V 3PH 51.1KW
168-122571-016	3 DIA
214017	TYPE CMX
Tmo -12-024p-E2 240v 2-	
4432-14810000	THREE PHASE CONTACTOR POWER CONTROL PANEL
Kb15	
4232-1410000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
296-120971-036	EXPANSION TANK ASSEMBLIES
063-057588-014	240V, 3 PHASE
Tmo -12-024p-E4 480v 1-	
4233-1510000	THREE PHASE THREE-LEG ZERO FIRED SIX SCR POWER CONTROL PANEL
296-123419-009	EXPANSION TANK ASSEMBLIES
4432-28010000	THREE PHASE CONTACTOR POWER CONTROL PANEL
4463-10000	MULTI-ZONE CONTACTOR POWER CONTROL PANEL NEMA 4X RATED
063-120517-010	480V, 3 PHASE
Tmo -18-020p-E1 240v 3-	
700242	XPMC-12221T2
4233-1010000	THREE PHASE THREE-LEG ZERO FIRED SIX SCR POWER CONTROL PANEL

063-120517-002	480V, 3 PHASE
Tmo -12-012p-E2 480v 1-	
063-120517-027	240V, 3 PHASE
Tmo -12-020p-E1 480v 1-	
063-120517-013	240V, 3 PHASE
4268-34000	THREE PHASE TWO-LEG ZERO FIRED SCR MINI POWER CONTROL PANEL
4432-18010000	THREE PHASE CONTACTOR POWER CONTROL PANEL
4236-42410000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
Tmo -03-006p-E1 240v 1-	
Tmo -03-009p-E2 480v 1-	
295806	SDRA-CC-30-43 30KW 480V 3PH
063-120517-006	480V, 3 PHASE
296-120971-006	EXPANSION TANK ASSEMBLIES
4436-54810000	THREE PHASE CONTACTOR POWER CONTROL PANEL
Tmo -06-030p-E1 240v 2-	
4214-35000	4214 SINGLE PHASE ZERO FIRED SCR POWER CONTROL PANEL
296-123419-001	EXPANSION TANK ASSEMBLIES
4133-05100	THREE PHASE THREE-LEG ZERO FIRED SCR POWER CONTROL PANEL
063-120517-001	240V, 3 PHASE
700031	XPMC-6121T3
296-121087-002	EXPANSION TANK ASSEMBLIES
063-120517-026	480V, 3 PHASE
219740	HVH-50-23-30 208/240V 3PH 38.4/51.1KW
296-120971-004	EXPANSION TANK ASSEMBLIES
296-121087-001	EXPANSION TANK ASSEMBLIES
4432-12410000	THREE PHASE CONTACTOR POWER CONTROL PANEL
063-120517-036	480V, 3 PHASE
4235-54810000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
4236-24810000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
Tmo -12-020p-E2 480v 1-	
Tmo -12-036p-E4 240v 2-3p	
214201	TYPE CMX
Tmo-03-003p-E2 480v 1-3	
4236-37210000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
Tmo -06-025p-E2 240v 2-	

296-120971-008	EXPANSION TANK ASSEMBLIES
306037099	
0135-30491	ITLS-DIGITAL CONTROL 15" DISPLAY, PROGRAMMED
063-120517-022	480V, 3 PHASE
4233-1210000	THREE PHASE THREE-LEG ZERO FIRED SIX SCR POWER CONTROL PANEL
296-120971-001	EXPANSION TANK ASSEMBLIES
295822	SDRA-CC-48-43 48KW 480V 3PH
296-123419-002	EXPANSION TANK ASSEMBLIES
063-120517-017	240V, 3 PHASE
4133-09100	THREE PHASE THREE-LEG ZERO FIRED SCR POWER CONTROL PANEL
0.315	
4131-09100	CLASS I, CLASS 1 2, GROUP B, C, D, CLASS 2, DIV 1 2, GROUPS E, F, G.
214113	TYPE CMX
219619	HVH-25-63-30 600V 3PH 25.0KW
219731	HVH-45-63-30 600V 3PH 45.2KW
219707	HVH-40-63-30 600V 3PH 37.5KW
4224-34000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
219563	HVH-20-23-30 208/240V 3PH 14.7/19.8KW
4131-01100	CLASS I, CLASS 1 2, GROUP B, C, D, CLASS 2, DIV 1 2, GROUPS E, F, G.
Tmo -12-018p-E2 480v 1-	
214156	TYPE CMX
Tmo -06-009p-E2 480v 1-	
4432-64810000	THREE PHASE CONTACTOR POWER CONTROL PANEL
4268-64000	THREE PHASE TWO-LEG ZERO FIRED SCR MINI POWER CONTROL PANEL
063-057588-003	480V, 3 PHASE
Tmo -03-003p-E2 240v 1-	
063-120517-009	240V, 3 PHASE
219723	HVH-45-43-30 480V 3PH 44.8KW
Tmo -12-036p-E4 480v 1-	
4131-11100	CLASS I, CLASS 1 2, GROUP B, C, D, CLASS 2, DIV 1 2, GROUPS E, F, G.
214172	TYPE CMX
4132-09110	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL
4463-20000	MULTI-ZONE CONTACTOR POWER CONTROL PANEL NEMA 4X RATED
063-120517-035	240V, 3 PHASE
4233-0310000	THREE PHASE THREE-LEG ZERO FIRED SIX SCR POWER CONTROL PANEL
4236-17210000	THREE PHASE TWO-LEG ZERO FIRED SCR POWER CONTROL PANEL

[4268-33000](#)

THREE PHASE TWO-LEG ZERO FIRED SCR MINI POWER CONTROL PANEL