

Hochiki

Garanti: 12 ay
Bu ürüne ait Türkiye içi kapı teslim fiyat ve teslim süresi içeren teklifimizi almak için **info@yursat.com.tr** e-posta adresine başvuru yapabilir ya da ayrıntılı bilgi için +90 224 240 03 04 numaralı telefonumuzdan bizlere ulaşabilirsiniz.
Hochiki Markası, tedarik süresi için lütfen bizimle iletişime geçiniz.

Firmamız Hochiki Türkiye Distribütörü veya temsilcisi değildir. Firmamız sipariş durumunda, belirtilen ürünlerde sadece Orjinal ve yeni ürün teklifi sunmaktadır. Bu sitede gösterilen Özel marka adları ve ticari markalar ilgili sahiplerinin mülkiyetindedir, talep durumunda kaldırılmaktadır.



Ürün	Açıklama
Fnp1127us2ers120	FIRENET PLUS FACP, 1 LOOP, W/DIALER, EXPANDABLE, RED, 120V
Ns-24mcw-Fr	
Sfh45-153075r-25s	
Sh24c-177r	
Dh-99a	
Hec24-75ww	
Fnencbcr9th	
Hps-Bb	
Fnp-1127e-Bo	
Hp-24tr	
Fn-4127n-220v	ANALOG /ADDRESSABLE FIRE CONTROL PANEL (4 LOOP/4AMP PS) W/NETWORK CARD (220V) W/

Sprm	
B02002-00	
B02410-01	
Sfh45-75110r-25r	
Fn-Enc-Bc-Dd	
Hes24-177pww	
Fn-642-Ulada-R	
Glassrods	
Gus9-16	FIRENET GRAPHIX SOFTWARE PACKAGE- 9 TO 16 NODES
Fnv-100	100WATT VOICE EVACUATION MODULE WITH MICROPHONE
Nstt-H	
Fnm-Frcma	
Evax-50e	TEMPORAL PATTERN, POWER SUPPLY AND BATTERY
Sra-24reflector	
Fn-Lcd-N-Bb-G	
Fnv-50em	50 WATT EXPANDER MODULE WITH MICROPHONE. NO DMR)
Fn-Ctm	
Sbc-4/24w	
Fn-Lcd-N-Etr-R	
Fnm-Aca-V	
Sfh47-153075r-25s	
Fnv-Ioi	
Slr-24f	
Dsc-Ea	
Sig24	
Hp-25tw	
End Device - Not Hochikiã39;S	
Rai-Led	
Fn-2127-Ddw-C	ANALOG/ ADDRESSABLE FIRE CONTROL PANEL (2 LOOP/4AMP PS) WITH PLEXIGLASS WINDOW, CHARCOAL
Hes24-177ww	

R2mh-I	
Fn-Lcd-S-Bb-R	
Tse-A100	SMOKE GENERATOR POLE
Hec3-24ww	
Evax-200r/12z	EVAX 200 PANEL WITH 12 SPEAKER ZONES, RED CABINET
Fn2127us0ers120	ANALOG ADDRESSABLE FIRE CONTROL PANEL, 2 LOOP, RED
Sif-24f	
Fnv-M-Dr	
B03100-0	
Evax-400e	100 WATT AMPLIFIERS/SPEAKER CIRCUITS), GRAY CABIN
Ybc-RI/12	
Evax-150r	EVAX 150 PANEL. RED CABINET
Fnv-Mfh	
Slr-835bh-2w	
Fnv-100e	100 WATT EXPANDER MODULE (NO MICROPHONE, NO DMR)
Evax-150r/12z	EVAX 150 PANEL WITH 12 SPEAKER ZONES, RED CABINET
Hec24-177wr	
Fn-Pmp	
Evax-200emr	200 WATT EXPANDER PANEL W/ MICROPHONE, W/O DMR, RED CABINET
Guc232a	
Sfh47-75110r-70s	
Hmcc-1024-6	
Evx-2za	
Evax25r/2za	EVAX-25 PANEL WITH 2 CLASS A SPEAKER ZONES, RED CABINET
Ms-Ra	
Evax-50/8z	EVAX 50 PANEL WITH 8 SPEAKER ZONES, GRAY CABINET
Alg-V(Blk)	
Fn-642-Ulada-G	
Shp24-153075r	

Hcp-204e	
Fn-2127nc	ANALOG /ADDRESSABLE FIRE CONTROL PANEL (2 LOOP/4AMP PS) W/NETWORK CARD W/MANUAL, CHARCOAL
Frcme-A	
En54-7-2000 Replaced By Aln-En M (010-095)	
0200-03660	
Evx-Byc-4-H	
B02011-00	
Som-A-I	
Fn-Enc-Do-C	
Evax-25e	TEMPORAL PATTERN, POWER SUPPLY AND BATTERY
Slr-835	
Slr-24dh	
Dcp-Som-Ai	
Evax-50r	EVAX 50 PANEL. RED CABINET
Fn2127us0egs120	ANALOG ADDRESSABLE FIRE CONTROL PANEL, 2 LOOP, GRAY
Sp4-Loc-Sb	SURFACE MOUNT LOCAL OPERATOR CONSOLE
Fnv-Mfp-Hs	
Dcd-Ae3	
Evax-150	INCLUDES DMR, TEMPORAL PATTERN, POWER SUPPLY AND BATTERY CHARGER.
Fn-2127c	ANALOG/ ADDRESSABLE FIRE CONTROL PANEL (2 LOOP/4AMP PS), CHARCOAL
Fnp-1127-Enc-Bc	
Hes24-75wr	
Fn-4127nc	ANALOG /ADDRESSABLE FIRE CONTROL PANEL (4 LOOP/4AMP PS) W/NETWORK CARD W/MANUAL, CHARCOAL
Tch-B100	
Frcma/1	
Fnv-Dps25/P	DISTRIBUTED PANEL, SINGLE CHANNEL, 25W, FIRE PHONE
Fn-Lcd-S-Bo	
Heh12-Pw	

Fnp-Etr-R	
Rfd-2000x	UV/IR FLAME DETECTOR (STAINLESS STEEL)
Evax-25	INCLUDES DMR, TEMPORAL PATTERN, POWER SUPPLY AND BAT
Fn-Enc-C	
Fn-4127-Cpa-Bo	
Fnv-Fo	
Chq-Szm2(Sci)	
Evax50c8zm120	50 WATT VOICE EVACUATION PANEL W/DMR, MIC, 8 CLASS B SPKR CKT, CHARCOAL CAB-1, 120V
Pfc-4410-Wc	PT-4 ZONE AGENT OR WATER RELEASING PANEL, 4 INPUTS, 4 OUTPUTS, 1 SUPERVISORY, WHITE CABINET
Fn-4127-220v	ANALOG /ADDRESSABLE FIRE CONTROL PANEL (4 LOOP/4AMP PS) (220V) W/MANUAL(JUMPER/L
Fn-Lcd-N-Ct	NETWORK ANNUNCIATOR W/TRIM RING (CHARCOAL)
Fnp-1127-Enc-Do	
Fn-Etr-C	
Sfh45-153075r-70s	
Hcp-1008e (220 Vac)	8 ZONE DIP SWITCH FIRE ALARM CONTROL PANEL 220V
Sfh47-153075r-70r	
Fnp-1127de-C	ANALOG ADDRESSABLE 1 LOOP W/INTEGRATED DIALER, EXPANDABLE, CHARCOAL
Heh24-W	
Evax-300e	100 WATT AMPLIFIERS/SPEAKER CIRCUITS), GRAY CABIN
Hcp-E	
Fn-2127-Ddwn-R	ANALOG/ ADDRESSABLE FIRE CONTROL PANEL (2 LOOP/4AMP PS) WITH PLEXIGLASS WINDOW , W/NETWORK CARD, RED
Fn-Enc-Dd-R	
Hocdimdimm	
Sh-1224wp-R	
Hps-Dbb	
Sr Mounting Box	
Chq-Ab	

Dh24120gb2	
Evax-25er	25-WATT EXPANDER PANEL W/O DMR OR PAGING MICROPHONE. RED
Gus5-8	FIRENET GRAPHIX SOFTWARE PACKAGE- 5 TO 8 NODES
Sij-24	
Evax50r8zm120	50 WATT VOICE EVACUATION PANEL W/DMR, MIC, 8 CLASS B SPKR CKT, RED CAB-1, 120V
Hcfg	
Eolr-12	
Env-Dps100/P	DISTRIBUTED PANEL, SINGLE CHANNEL, 100W, FIRE PHONE
Hx93-R	
Env-Dps50	DISTRIBUTED PANEL, SINGLE CHANNEL, 50W
Pfc-100rc	
Slb24-75cr	
Nh-12/24-W	
Sci-B4	
Atj-Ea	
Hes3-24pww	
Sif-E	
Frmce-A-I	
Ssc8-3075110r	
Dh-98i	
Hs24-60wr	
Evax-100/8z	EVAX 100 PANEL WITH 8 SPEAKER ZONES, GRAY CABINET
Ns-24mcw-Fw	
Slr-E-Is	
Evax50c4zm120	50 WATT VOICE EVACUATION PANEL W/DMR, MIC, 4 CLASS B SPKR CKT, CHARCOAL CAB-1, 120V
Env-Mbr	
Env-Evx-Cab-1r	
Dcc-2el	
Fnp1127us20rs120	ANALOG ADDRESSABLE 1 LOOP W/ INTEGRATED DIALER, NOT EXPANDABLE, RED

Tsa-B110	SMOKE DETECTOR TEST BOX
Fn-Lcd-N-Bo	
Sbp-1	
Fn-4127-Bo	
Hs24-60ww	
Fnp-1127us0ers-120	FIRENET PLUS FACP, 1 LOOP, EXPANDABLE, RED, 120V
Fnv-Mp80/P	MASTER PANEL, 80 SWITCH / 48 INPUT, MASTER FIRE PHONE
Ashp-Acsmr-25	
Tch-B200	
Evax-100/4z	EVAX 100 PANEL WITH 4 SPEAKER ZONES, GRAY CABINET
Fnv-Dp100-42	42 X26 X 6 CABINET
Evax-50/12z	EVAX 50 PANEL WITH 12 SPEAKER ZONES. GRAY CABINET
Ps-Exp	
Evax25/4za	EVAX-25 PANEL WITH 4 CLASS A SPEAKER ZONES, GRAY CABINET
Ns6-220	
Fn-2127n-220v	ANALOG /ADDRESSABLE FIRE CONTROL PANEL (2 LOOP/4AMP PS) W/NETWORK CARD (220V) W/
Fnv-Fpi	
Fnv-Ri	
Evax-150em	150 WATT EXPANDER PANEL W/ MICROPHONE, W/O DMR, GRAY
R2m-H	
Sh24w-75110r	
Fn-2127-Ny-R	ANALOG ADDRESSABLE FIRE CONTROL PANEL, 2 LOOP, WITH PLEXIGLASS WINDOW, NYC LOCK, RED
Hf-24 , Alternative B05401-00!!!!	
Evax-600er	600 WATT EXPANDER PANEL W/O DMR OR MICROPHONE, RED CABINET
Evax150r12zm120	150 WATT VOICE EVACUATION PANEL W/DMR, MIC, 12 CLASS B SPKR CKT, RED CAB-2, 120V
Slr-24vn	
Fn-4127-Ddw-R	ANALOG/ ADDRESSABLE FIRE CONTROL PANEL (4 LOOP/4AMP PS) WITH PLEXIGLASS WINDOW, RED

Evax50r4zm120	50 WATT VOICE EVACUATION PANEL W/DMR, MIC, 4 CLASS B SPKR CKT, RED CAB-1, 120V
Dcd-190	
Evax-200r/8z	EVAX 200 PANEL WITH 8 SPEAKER ZONES, RED CABINET
Ir2-Uv-Ex	EXPLOSIVE PROOF RATED
Mx-Fo	
Dcp-Frcme-P	
Evax-600e	100 WATT AMPLIFIERS/SPEAKER CIRCUITS), GRAY CABIN
Fnlcdsus00g024	
Fh-47r-25s	
Sp4-Tzc	
Hes24-60pwr	
Dcp-Ams	
Solo108	
Fnv-Dps50/P	DISTRIBUTED PANEL, SINGLE CHANNEL, 50W, FIRE PHONE
Bk-2	
Fn-4127-Ddwn-C	ANALOG/ ADDRESSABLE FIRE CONTROL PANEL (4 LOOP/4AMP PS) WITH PLEXIGLASS WINDOW, W/NETWORK CARD, CHAR
Hdact-100	
Hcp-W (Red) - Unknown Model	
C900v2	
Fn-4127n	ANALOG /ADDRESSABLE FIRE CONTROL PANEL (4 LOOP/4AMP PS) W/NETWORK CARD W/MANUAL, RED
Hec3-12pwr	
Fn-Eck	
Evx-4z	
Evax25r4zm120	25 WATT VOICE EVACUATION PANEL W/DMR, MIC, 4 CLASS B SPKR CKT, RED CAB-1, 120V
R2ml	
Gusr2004	2-4 WORKSTATIONS (4 REPEATER PACKAGE)- OPTIONAL ADDITIONAL 2-4 LICENSES FOR USE WITH PACKAGES, NO PH
Dcp-Ams-Lp/S	
Hps-Dakcat30	

Fnv-Dp25	DISTRIBUTED PANEL, DUAL CHANNEL, 25W
Hec3-12wr	
Som	
Mba-10	
Fnv-Dp200rp42120	100 WATT AMPLIFIERS), 4 FIR
Fn-300ulx-G	
Fnp1127us0egs120	ANALOG ADDRESSABLE 1 LOOP NO DIALER, EXPANDABLE, GRAY
Nsrt-H	
Slr-835bh-2	
Hsc-224l	
808401347 -Unknown Model	
Hcp-202	
Fnv-Ev-Spkr-4w	
Fn-300ulx-C	
Dcp-Ams-Kl-Lp/S	
Fnv-50	50 WATT VOICE EVACUATION MODULE WITH MICROPHONE
Fnp-1127-Enc-C	
Fnv-Dp50/P	DISTRIBUTED PANEL, DUAL CHANNEL, 50W, FIRE PHONE
Pfc-Tr	
Fn-Natc	
Evax-25/4z	EVAX-25 PANEL WITH 4 SPEAKER ZONES, GRAY CABINET
Fn-2127c-220v	ANALOG /ADDRESSABLE FIRE CONTROL PANEL (2 LOOP/4AMP PS) (220V) CHARCOAL GREY W/M
Banshee Exel Ip 66	
Pba-10	
Slr-24h	
Evax-25r/4z	EVAX-25 PANEL WITH 4 SPEAKER ZONES, RED CABINET
Fnv-Dp100	DISTRIBUTED PANEL, DUAL CHANNEL, 100W
Hcp-E(Sci), Sr2t	
Sp4-Loc-Fb	

Dh-98hvp	
Evax-100r/12z	EVAX 100 PANEL WITH 12 SPEAKER ZONES, RED CABINET
Fnm-Ams-Kl-Lp	
Evx-Ba-100	
Hsc-224r	
Atg-E - Is Atj-En(Wht)	
Fn-4127-IO	
Mx-Fj	
Fn-2127nc-220v	ANALOG /ADDRESSABLE FIRE CONTROL PANEL (2 LOOP/4AMP PS) W/NETWORK CARD (220V) CH
FNV-EVX-BB-2	
Evax25/2za	EVAX-25 PANEL WITH 2 CLASS A SPEAKER ZONES, GRAY CABINET
Slr-835b-4	
Dcp-Ams-Lp	
Fn-Lcd-N-C	NETWORK ANNUNCIATOR (CHARCOAL) W/MANUAL
Aca-E- , - Acc-En	
Hes24-60wr	
Hps-Sa-Ex/Wp	
Ashx-24smr-70	EXPLOSION-PROOF (CLASS I, DIV. 1, GROUPSB, C, D) SPEAKER AMPLIFIER 24VDC, 70
Hps-Dak-Sr	
Pfc-100rc-Pcb	
FNV-EV-SAB	
Gus33+	FIRENET GRAPHIX SOFTWARE PACKAGE- 33+ NODES
Spc-1	
Fn-Dc	FIRENET DEMO CASE
FNV-EVX-CAB-42	26 X 42 X 6 W-H-D CABINET, GRAY
FNV-DPS100/P-42	42 X26 X
Kentec H80161 M2	
Da-C/S	
Evax-200r/16z	EVAX 200 PANEL WITH 16 SPEAKER ZONES, RED CABINET

Evax50/4za	EVAX 50 PANEL WITH 4 CLASS A SPEAKER ZONES, GRAY CABINET
Fn-1042-Ulada-B	
Ssc2-3075110w	
Ashp-24smr-70	
Dcd-1e(Is)	
Fn-1042-Ulada-R	
Alk-E - Not Available	
Hec24-60pwr	
H-1224r	
Fnp-Man	
Fn-400ulx-R	
Evax-25r/8z	EVAX-25 PANEL WITH 8 SPEAKER ZONES. RED CABINET
Fn-Enc-Bc-C	
Hes24-110ww	
Sh24c-3075110r	
4bx-5w	
Alk-V	
Fn-Lcd-N-Rt	NETWORK ANNUNCIATOR W/TRIM RING (RED)
Sfh47-75110r-25r	
Evx-Za	
Slr-835+ns6-220	DET SMK SLR-835+NS6-220 W/BASE 60PCS SET
Fnencbcdrr	
Heh12-Pww	
Heh24-Wr	
Fn-4127-Slc	
B02401-00	
Frcma-I	
Som-A	
Fmv-Mp16/P	MASTER PANEL, 16 SWITCH / INPUT, MASTER FIRE PHONE

Fn-Ps402	
Scm-24w-75110r	
Hec24-177pww	
Fnv-Mp48/P	MASTER PANEL, 48 SWITCH / 32 INPUT, MASTER FIRE PHONE
Fnp-1127-Bo	
Fh-47r-25r	
Evx-OI8-H	
Hec24-15ww	
Call Point	
Sp-Coa	
Slr-Em	
Hs24-1575pww	
Fn-2127-Ddw-R	ANALOG/ ADDRESSABLE FIRE CONTROL PANEL (2 LOOP/4AMP PS) WITH PLEXIGLASS WINDOW, RED
Eol	
Chq-Ws2	
Fnv-25e	25 WATT EXPANDER MODULE (NO MICROPHONE, NO DMR)
Ge/Ifsd1300	RS485 TO FIBER CONVERTER, TRANSCEIVER GE/IFS D1300 24VDC
B02322-00	
Evax-200em	200 WATT EXPANDER PANEL W/ MICROPHONE, W/O DMR, GRAY
Pba-8-120	
Fn-300ulx-R	
FnIctnus00g024	NETWORK ANNUNCIATOR W/TRIM RING (GRAY)
Fnv-Ev-Str-110	
Fnv-Dps25	DISTRIBUTED PANEL, SINGLE CHANNEL, 25W
Frcme-P	
Fn-V187	
Evax-25em	25 WATT EXPANDER PANEL WITH MICROPHONE, WITHOUT DMR, GRAY
Fn-4127-Ddw-C	ANALOG/ ADDRESSABLE FIRE CONTROL PANEL (4 LOOP/4AMP PS) WITH PLEXIGLASS WINDOW, CHARCOAL

Evax-50/4z	EVAX 50 PANEL WITH 4 SPEAKER ZONES, GRAY CABINET
Env-Sp6	
Slr-835w	
Hps-Dak	
Evax-100r	EVAX 100 PANEL. RED CABINET
Fn-4127nc-220v	ANALOG /ADDRESSABLE FIRE CONTROL PANEL (4 LOOP/4AMP PS) W/NETWORK CARD (220V) CH
TI-205	TEST LAMP FOR RDF-2000X
Evx-Rly-H	
Sfh45-153075r-70r	
Spmb4z	
Fnp-1127-C	ANALOG ADDRESSABLE 1 LOOP NO DIALER, NOT EXPANDABLE, CHARCOAL
Dfj-Ae3	
Env-Evx-Cab-1	
Fn-842-Ulada-C	
Mx-Mfp-Hs	
Pb-Sa	
Cam	
Ybn-R/6	
Env-100em	100 WATT EXPANDER MODULE WITH MICROPHONE. (NO DMR)
Evax200r8zm120	200 WATT VOICE EVACUATION PANEL W/DMR, MIC, 8 CLASS B SPKR CKT, RED CAB-2, 120V
Hs24-1575pwr	
Fnaccg	
Alg-V	
Fnp-1127d-C	ANALOG ADDRESSABLE 1 LOOP W/INTEGRATED DIALER, NOT EXPANDABLE, CHARCOAL
Chq-Dim(Sci) Obsolete , Successor Is Chq-Dim2(Sci)	
Frcma	
Fnldnus00g024	NETWORK ANNUNCIATOR (GRAY) W/MANUAL

Alk-E (Wht) - Not Available, Similar Product Rm 3.3	
Fmv-Dfp-2	
Mx-Llc	
Evax-100e	
Dimm	
Sts-2.5	
Hec24-15wr	
Slr-24v+ns6-220	DET SMK SLR-24V+NS6-220 W/BASE 60PCS SET
Hes3-24wr	
Hcc24cw	
Ssc25-3075110r	
Ms-Rh/Ka/P/R	
Asb	
Fn-4127-Ny-R	ANALOG ADDRESSABLE FIRE CONTROL PANEL, 4 LOOP, WITH PLEXIGLASS WINDOW, NYC LOCK, RED
Hrm-204	
SI24c-177r	
Evax-50/16z	EVAX 50 PANEL WITH 16 SPEAKER ZONES, GRAY
Mx-Mbi	
Evx-Byc-H	
Evax-150/12z	EVAX 150 PANEL WITH 12 SPEAKER ZONES, GRAY CABINET
Evax-100r/4z	EVAX 100 PANEL WITH 4 SPEAKER ZONES, RED CABINET
Fnm-2127-C	FIRENET MARINE PANEL, 2-LOOP, GRAY
Evax50/2za	EVAX 50 PANEL WITH 2 CLASS A SPEAKER ZONES, GRAY CABINET
Nstp-15a	
Sts-10	
Evax-50r/16z	EVAX 50 PANEL WITH 16 SPEAKER ZONES. RED CABINET
Atj-En(Wht)	
Hsc-221I	
Rms-L&Amp;P-Nyc	

Slv-24	
Hes24-15wr	
Hes24-1575pwr	
Slv-24m	
Hes24-177wr	
Fnp-1127-Enc-R	
Gusr2001	
Tch-B100 - (By Tch-B200)	
Ns6-220m	
Acb-Ew	
Heh24-R	
Sbc-2rw	
Ns6-221	
Fn-4127-Ddwn-R	ANALOG/ ADDRESSABLE FIRE CONTROL PANEL (4 LOOP/4AMP PS) WITH PLEXIGLASS WINDOW, W/NETWORK CARD, RED
Dh24120gc1	
Evax-25emr	25 WATT EXPANDER PANEL WITH MICROPHONE, WITHOUT DMR, RED
Slr-835w+ns6-220	DET SMK SLR-835W +NS6-220W W/BASE 60PCS SET
Mx-Ri	
Slr-835b-2	
Slr-835b-2w	
Fnm-2127-R	FIRENET MARINE PANEL, 2-LOOP, RED
Hes24-30wr	
Evx-II8-H	
Fn-Ps776	
64460045	
Hmx-Dp200-42	42 X
Evax200c16zm120	200 WATT VOICE EVAC. PANEL W/DMR, MIC, 16 CLASS B SPKR CKT, CHARCOAL CAB-2, 120V
Atg-Ea	
FnIcdnus00r024	NETWORK ANNUNCIATOR (RED) W/MANUAL

Alg-En Repalced By (B02002-00 Aln-En)	
Dcd-1e-Is	
Evax-100r/16z	EVAX 100 PANEL WITH 16 SPEAKER ZONES, RED CABINET
Env-M-Bbr	
Fh-45r-703s	
Fn-S-Dd	
Fnp1127us20gs120	ANALOG ADDRESSABLE 1 LOOP W/ INTEGRATED DIALER, NOT EXPANDABLE, GRAY
Evax-50r/4z	EVAX 50 WITH 4 SPEAKER ZONES. RED CABINET
Evax-25/8z	EVAX-25 PANEL WITH 8 SPEAKER ZONES, GRAY CABINET
Fn-Lcd-S-C	
Fnpetrg	
Evax-150e	TEMPORAL PATTERN, POWER SUPPLY AND BATTERY
Hes24-15ww	
Alk-E (Hfp) - Aln-En	
Fnp1127us00gs120	ANALOG ADDRESSABLE 1 LOOP NO DIALER, NOT EXPANDABLE, GRAY
Sra-24	
Tse-P100	
Fnm-Lcd-S-R	
Hec24-60ww	
Hcs24cr	
Hec24-15pwr	
Fh-47r-70r	
Rxb-1r	
Sfh47-153075r-25r	
Tzc-Usb	
Slr-24v	
Sfh45-153075r-25r	
Evax-150/16z	EVAX 150 PANEL WITH 16 SPEAKER ZONES, GRAY CABINET
Hsb-Nsa-6	
Fn-Etr-R	

Chq-Wsb	
R2ml-I	
4bx-3r	
Sci-B6	
Evax150c12zm120	150 WATT VOICE EVAC. PANEL W/DMR, MIC, 12 CLASS B SPKR CKT, CHARCOAL CAB-2, 120V
Fn-600ulx-R	
Fnm-Lcd-S-C	
Fnlcdnt-R	
Fnv-Nys	
Tsc-A100/Holder	
Sbc-4/12	
Fnp-1127-Mp	
Fnm-R2ml	
Evax-200/8z	EVAX 200 PANEL WITH 8 SPEAKER ZONES, GRAY CABINET
Ca2z	
Fnm-Nsa-6	
Hec24-110ww	
Fnv-Brk	
Evax-50emr	50 WATT EXPANDER PANEL W/ MICROPHONE, W/O DMR, RED CABINET
Hec3-24wr	
Hsb-Nsa-6(Blk)	
Fn-1042-Ulada-G	
Hec24-177ww	
Dfe-190	
Evax-100emr	100 WATT EXPANDER PANEL W/ MICROPHONE, W/O DMR, RED CABINET
Hec24-75pwr	
Ashh-24smr-70	
Fn-Lcd-Nyn-R	NETWORK ANNUNCIATOR (RED) (W/O RESET CAPABILITY)

B02220-00	200 WATT VOICE EVACUATION PANEL W/DMR, MIC, 16 CLASS B SPKR CKT, RED CAB-2, 120V
Evax200r16zm120	
Slr-835bh-4	
Evax-50r/8z	EVAX 50 WITH 8 SPEAKER ZONES. RED CABINET
B05401-00	
SI-1224wp-R	
Fnm-Alk-V	
Fnv-Dp100/P	DISTRIBUTED PANEL, DUAL CHANNEL, 100W, FIRE PHONE
Evax-150r/16z	EVAX 150 PANEL WITH 16 SPEAKER ZONES, RED CABINET
Ms-Ra/P/R	
Pe-10sn(110v)	
Fnv-Dp100rp42120	42 X 26
Wcp1a-Ra470sf-H029-01 - Is Ccp-W	
Fnp-Key-S	
Fn-Acc-C	
Hp-25tr	
Fnv-Evx-Dr-2r	
Fn-1024ulx-C	
Fn-2127-220v	ANALOG /ADDRESSABLE FIRE CONTROL PANEL (2 LOOP/4AMP PS) (220V) W/ MANUAL (JUMPER
Fnv-Mfi	
Hps-Sak-Ex/Wp	
Dcp-Dimm	
Evax-200e	TEMPORAL PATTERN, POWER SUPPLY AND BATTERY
Slk-24f	
Acc-V	
Sbx-1	
Solo100	
Mx-Mfa	
Fnp-1127e-R	ANALOG ADDRESSABLE 1 LOOP NO DIALER, EXPANDABLE, RED

Sp4-Loc-Kit Sfh45-75110r-70s	
Evax-200er	200 WATT EXPANDER PANEL W/O DMR OR MIC RED CABINET
Sza-Na(Fm)	HIGH SENSITIVITY SMOKE DETECTION SYSTEM
Fnv-M-Bb	
Fnv-Mp96/P	MASTER PANEL, 96 SWITCH / 48 INPUT, MASTER FIRE PHONE
Fnv-Dp100p-42	DISTRIBUTED PANEL, DUAL CHANNEL, 100W, 16 AUDIO, 4 FP CKTS, CAB 26 X 42 X 6
Fn-Lcd-S-R	
Alb-Ea	
Tcf-142-M-St	
Fnv-Mp16	MASTER PANEL, 16 SWITCH / INPUT
Fnv-Dp200r42120	42 X
Hca-8/120v	
Evax-200/16z	EVAX 200 PANEL WITH 16 SPEAKER ZONES, GRAY CABINET
Fnv-Dps100-42	42 X26 X 6 CABINET
Fn2127us0egd120	ANALOG ADDRESSABLE FIRE CONTROL PANEL, 2 LOOP, WITH PLEXIGLASS WINDOW, GRAY
Chq-Drc(Sci)	
Hes24-1575pww	
Fnv-50e	50 WATT EXPANDER MODULE (NO MICROPHONE, NO DMR)
Solo461complete	SOLO 461 (1) 460 HEAT TESTER, (1) 725 CHARGER, (2) 720 BATTERY
Hs24-30ww	
Fn-Lcd-N-R	NETWORK ANNUNCIATOR (RED) W/MANUAL
Evax-50er	50 WATT EXPANDER PANEL W/O DMR OR MIC RED CABINET
Fnlcdst-R	
Sl-1224wp-W	
Fnv-Dfp-1	
Heh12-Wr	
Hec24-1575wr	
Ms-Ka/R	

Battery 12v; 12ah	
Smp-101	
Dcp-Ams-Kl	
Ns6-224	
Hps-Sak-Psk	
Sbc-2w	
Hsgm-1004	
Ybn-Nsa-4	
Fnv-Ev-Ss-30	
Heh24-Pr	
Hs24-15ww	
Fn2127us0erd120	ANALOG ADDRESSABLE FIRE CONTROL PANEL, 2 LOOP, WITH PLEXIGLASS WINDOW , RED
Hps-Sah-Wp	
Ev-Dmr-H	
Fnp-1127-R	ANALOG ADDRESSABLE 1 LOOP NO DIALER, NOT EXPANDABLE, RED
Fn-2127n	ANALOG /ADDRESSABLE FIRE CONTROL PANEL (2 LOOP/4AMP PS) W/NETWORK CARD W/MANUAL, RED
Smokesabre	
Ssc70-3075110r	
Fnv-Dps100	DISTRIBUTED PANEL, SINGLE CHANNEL, 100W
SI24c-177w	
Pfc-4410rc-Pcb	
Hcp-W(Sci)	
Hec24-15pww	
Hes24-60ww	
Rsb24-153075r	
Fn2127u	
Fnv-Ev-Ss-110	
Fnlcdst-G	
Led Indicator For Slr-E3n	

Evax-150er	150 WATT EXPANDER PANEL W/O DMR OR MIC RED CABINET
Hsc-220I	
Hec24-30pwr	
Mba-8-12	
Hd7033	
Dcd-1e - Is Dcd-Ae3	
Hcs24cw	
Fnm-Nsa-4	
Fnv-Mp32/P	MASTER PANEL, 32 SWITCH / 16 INPUT, MASTER FIRE PHONE
Pam-4	
Hec24-1575ww	
Fn-BIj	
Hps-Dah/S	
Fn-Lcd-N-Cpa-Bo	
Gus1-4	FIRENET GRAPHIX SOFTWARE PACKAGE- 1 TO 4 NODES
Fnv-Ev-Spkr-4	
B02472-00	
Sh24w-153075r	
Spc-24	
Y Bf-RI/4h3h , By Ybf-RI/4h5	
Fn-Prc	
Ms-Ra/P	
Evx-Sc	
Hs24-75ww	
Ashx-24smr-25	EXPLOSION-PROOF (CLASS I, DIV. 1, GROUPSB, C, D) SPEAKER AMPLIFIER 24VDC, 25
Ssc8-3075110w	
Chq-Dim2(Sci)	
Hes24-60pww	
B05406-00	
Dh24120sb	

Sfh47-75110r-70r	
Hps-Sah	
B02431-00	
Sfh47-75110r-25s	
Fn-300ulx-B	
Fn-642-Ulada-C	
Shb24-75cr	
Fn-4127	ANALOG /ADDRESSABLE FIRE CONTROL PANEL (4 LOOP/4AMP PS) W/MANUAL, RED
Heh24-Ww	
Sgp-R	
Hes24-75pwr	
Scm-24c-177r	
Fnp-1127e-C	ANALOG ADDRESSABLE 1 LOOP NO DIALER, EXPANDABLE, CHARCOAL
Dcd-135	
Spb-24	
Hp-24r	
Evax200c8zm120	200 WATT VOICE EVACUATION PANEL W/DMR, MIC, 8 CLASS B SPKR CKT, CHARCOAL CAB-2, 120V
Fn-Enc-Bc-R	
Hes3-12pww	
H24wr	
Fnv-Aor	
Dh-98hvi	
Fn-Acc-R	
Hec3-12ww	
Hocfrma	
Fnv-Slc	
Fnp-1127-Slc	
Alg-En (Wht)	
Fnv-Ev-Ssynch	

Hsc-4r/12w	
Frcme-S	
Hs24-30pww	
Czm	
Hsc-221r	
Evax-300er	300 WATT EXPANDER PANEL W/O DMR OR MICROPHONE, RED CABINET
Alh-E (Wht)	
Evax-200/12z	EVAX 200 PANEL WITH 12 SPEAKER ZONES, GRAY CABINET
Evax-25r	INCLUDES DMR, TEMPORAL PATTERN, POWER SUPPLY AND BAT
Ssc8-177r	
Evax-100er	100 WATT EXPANDER PANEL W/O DMR OR MIC RED CABINET
Hcc24cr	
Fnp-1127de-R	ANALOG ADDRESSABLE 1 LOOP W/INTEGRATED DIALER, EXPANDABLE, RED
Sp40s-B	
Fnv-Ev-Ss-75	
Asbl	
Hdm-204	
Evax100r4zm120	100 WATT VOICE EVACUATION PANEL W/DMR, MIC, 4 CLASS B SPKR CKT, RED CAB-1, 120V
Ns4-224	
Ap-15tuc	
Frcme-4	
Fn-400ulx-C	
Evx-Rmr	
Fn-Lcd-N-Bb-R	
Evax-100/12z	EVAX 100 PANEL WITH 12 SPEAKER ZONES, GRAY CABINET
Ashp-24smr-25	
Fnv-Fsf	
Fnv-25em	25 WATT EXPANDER MODULE WITH MICROPHONE. (NO DMR)
Sh-1224r	

Pfc-4410-Rc	4 ZONE AGENT OR WATER RELEASING PANEL, 4 INPUTS, 4 OUTPUTS, 1 SUPERVISORY, WHIT
Fn-Cb-Dd	
Fnv-Ev-Str-75	
Hec24-60wr	
Fh-45r-253r	
Pba-8	
Fnp1127us2egs120	ANALOG ADDRESSABLE 1 LOOP W/ INTEGRATED DIALER, EXPANDABLE, GRAY
Fn-2127	ANALOG/ ADDRESSABLE FIRE CONTROL PANEL (2 LOOP/4AMP PS), RED
Hcp-204	
Hs24-30wr	
Fnv-Tc	
Fnv-Mp64/P	MASTER PANEL, 64 SWITCH / 32 INPUT, MASTER FIRE PHONE
Evax-100/16z	EVAX 100 PANEL WITH 16 SPEAKER ZONES, GRAY CABINET
Fnv-Dp25/P	DISTRIBUTED PANEL, DUAL CHANNEL, 25W, FIRE PHONE
Dcp-Som	
R2m-L	
Evax-50em	50 WATT EXPANDER PANEL W/ MICROPHONE, W/O DMR, GRAY CABINET
D262	
Gus17-32	FIRENET GRAPHIX SOFTWARE PACKAGE- 17 TO 32 NODES
Bbx-1	
Fnv-Ii	
Evax25c4zm120	25 WATT VOICE EVACUATION PANEL W/DMR, MIC, 4 CLASS B SPKR CKT, CHARCOAL CAB-1, 120V
Evax-150/8z	EVAX 150 PANEL WITH 8 SPEAKER ZONES, GRAY CABINET
Hcp-1008e	8 ZONE DIP SWITCH FIRE ALARM CONTROL PANEL, 110V/220V
Acc-En(Wht)	
Fn-2127-Ddwn-C	ANALOG/ ADDRESSABLE FIRE CONTROL PANEL (2 LOOP/4AMP PS) WITH PLEXIGLASS WINDOW, W/NETWORK CARD, CHAR
Hec24-110pwr	

FnIctnus00r024	NETWORK ANNUNCIATOR W/TRIM RING (RED)
Fnv-Mp96	MASTER PANEL, 96 SWITCH / INPUT
Evax-T17528	
Chq-Cp(Pcb)	
Nstt-C	
Fh-45r-703r	
Hech-1048	
Fnv-Evx-Cab-2	
Hec24-60pww	
Dfe-135	
Frcme-M	
Evax-500er	500 WATT EXPANDER PANEL W/O DMR OR MICROPHONE, RED CABINET
SI24w-153075r	
Fnv-Mfp	
Dcd-1e-1s	
Fnv-Pwr2a	
Gusr2008	5-8 WORKSTATIONS (8 REPEATER PACKAGE)
Chqdsc/ Oem(Sci	
Evax-50	INCLUDES DMR, TEMPORAL PATTERN, POWER SUPPLY AND BATTERY CHARGER. S
Hes3-24ww	
Evax-150emr	150 WATT EXPANDER PANEL W/ MICROPHONE, W/O DMR, RED CABINET
Fn-4127c	ANALOG /ADDRESSABLE FIRE CONTROL PANEL (4 LOOP/4AMP PS) W/MANUAL, CHARCOAL
Hs24-110ww	
Sh24w-153075w	
Fnv-25	25 WATT VOICE EVACUATION MODULE WITH MICROPHONE
Evax-150r/8z	EVAX 150 PANEL WITH 8 SPEAKER ZONES, RED CABINET
Nstp-15	
Hb-40	

Acae/ Wht/	
Fnlcdnt-G	
Slr-835bh-4w	
Fn-400ulx-G	
Hca-8d/120v	
X187	
Fnv-M-Cab-R	
Evax100c4zm120	100 WATT VOICE EVACUATION PANEL W/DMR, MIC, 4 CLASS B SPKR CKT, CHARCOAL CAB-1, 120V
Evax-100	INCLUDES DMR, TEMPORAL PATTERN, POWER SUPPLY AND BATTERY CHARGER.
Evax100c8zm120	100 WATT VOICE EVACUATION PANEL W/DMR, MIC, 8 CLASS B SPKR CKT, CHARCOAL CAB-1, 120V
Evx-Zab	
Pe-6sn	
Banshee Exel Lite	
Evax-100r/8z	EVAX 100 PANEL WITH 8 SPEAKER ZONES, RED CABINET
Testmagnet	
Fnv-Mp80	MASTER PANEL, 80 SWITCH / INPUT
Hps-Sah-Psk	
Chq-Sim	
Evax-400er	400 WATT EXPANDER PANEL W/O DMR OR MICROPHONE, RED CABINET
Mba-8	
Dh-98p	
Heh12-W	
SI24c-3075110w	
Sbc-4/24	
Hps-Cp	
Ybn-Nsa-4(Blk)	
Ssc25-177r	
Fnv-Ev-Cms-4	

Env-Asc	
Hx93-W	
Env-Xo	
Evax-200	INCLUDES DMR, TEMPORAL PATTERN, POWER SUPPLY AND BATTERY CHARGER.
Fn-Key	
Hps-Sak211key	
En54 Hpf Ap-2	
Env-Ev-Ss-15	
Hes24-1575wr	
Hps-Dak211key	
Sfh45-75110r-25s	
Hs24-110pwr	
Hs24-15pwr	
Hp-26r	
Pfc-4410rc-Ps	
Hec3-12pww	
Env-Ami	
Ybf-RI/4h5	
Fnp1127us00rs120	ANALOG ADDRESSABLE 1 LOOP NO DIALER, NOT EXPANDABLE, RED
Evx-Zm-H	
4bx-1	
Evax-500e	100 WATT AMPLIFIERS/SPEAKER CIRCUITS), GRAY CABIN
Env-Mp48	MASTER PANEL, 48 SWITCH / INPUT
Fn-1024ulx-R	
Dh24120fc	
Ashh-24smr-25	
Ashp-Acsmr-70	
Fnp-1127d-R	ANALOG ADDRESSABLE 1 LOOP W/INTEGRATED DIALER, NOT EXPANDABLE, RED
Hes24-75pww	

Ns4-220m	
Hes24-110wr	
Evax25r/4za	EVAX-25 PANEL WITH 4 CLASS A SPEAKER ZONES, RED CABINET
Fnn-Evx-Bb-2r	
Fn-4127c-220v	ANALOG /ADDRESSABLE FIRE CONTROL PANEL (4 LOOP/4AMP PS) (220V) CHARCOAL GREY W/M
SI24c-3075110r	
Scm-24c-3075110w	
Dh-98ar	
Chq-Mrci(Hfp)-Sci - Not Available, Similar Model Chq-Mrc2(Sci)	
Fn-4127-Nic	
Evax100r8zm120	100 WATT VOICE EVACUATION PANEL W/DMR, MIC, 8 CLASS B SPKR CKT, RED CAB-1, 120V
Hs24-110pww	
Sbc-4/12w	
Evax-50r/12z	EVAX 50 PANEL WITH 12 SPEAKER ZONES. RED CABINET
Fn-842-Ulada-G	
Ssc70-177r	
Fnn-Dp50	DISTRIBUTED PANEL, DUAL CHANNEL, 50W
Evax-T2885	
Fnn-Mp64	MASTER PANEL, 64 SWITCH / INPUT
Evx-Rm	
Scm-24w-153075r	
Shb120-75cr	
Fnn-Mp32	MASTER PANEL, 32 SWITCH / INPUT
Fnn-M-Cab	
Evx-Mic-H	
Fnn-Evx-Cab-2r	
Hmx-Dp200p-42	100 WATT AMPLIFIERS), 4 FIRE
Evax-200r	EVAX 200 PANEL. RED CABINET

[Spb-160-B](#)

[Ae2](#)

[Scm-24c-3075110r](#)