

Mountz

Garanti: 12 ay
Bu rne ait Trkiye ii kapı teslim fiyat ve teslim sresi ieren teklifimizi almak iin **info@yursat.com.tr** e-posta adresine bařvuru yapabilir ya da ayrıntılı bilgi iin +90 224 240 03 04 numaralı telefonumuzdan bizlere ulařabilirsiniz.
Mountz Markası, tedarik sresi iin ltfen bizimle iletiřime geiniz.

Firmamız Mountz Trkiye Distribtr veya temsilcisi deēildir. Firmamız sipariř durumunda, belirtilen rnlerde sadece Orjinal ve yeni rn teklifi sunmaktadır. Bu sitede gsterilen zel marka adları ve ticari markalar ilgili sahiplerinin mlkiyetindedir, talep durumunda kaldırılmaktadır.



rn	Aıklama
120171	
77007	(PRICE/EA) BMX250I TORQUE SENSOR (25-250 LBF.IN) ARCII
120260	
020082cal	
72014	
77001	(PRICE/EA) BMX40Z TORQUE SENSOR (4-40 OZF.IN) ARCII
81-1060	
20314	
020119	DDS800S DIAL WRENCH WITH LIGHT SIGNAL (3/4 SQ DR.)
020079caldu	
180035	
68345	

20367	
20388	
120777	
072606	MOUNTING BRACKET (FOR LTT MODELS)
20627	
68162	
068000-A	
290125	
20447	
060064	WHEEL 4 (1/4 3/8 MALE SQ DRIVE)
20437	
230563	
144249	SS6500X-ESD ELECTRIC DRIVER (1/4 F/HEX)
40089	
144352	(PRICE/EA) VZ-3012 ELECTRIC DRIVER 120V (1/4 F/HEX)
20-A90220	
145737	
144374	SS6500 ELECTRIC DRIVER (4MM HIOS DR.)
120178	
06005b-106-Tbcaldu	
145926	PUSH BUTTON
240191	TMS350 ELECTRONIC TORQUE SCREWDRIVER (1/4 SQ. DR.)
20593	
145753	
040039g	
126054	
144328	
144112	
20075	
121469	

68103	
68046	
260081	(PRICE/EA) EZ-12R ARTICULATED TORQUE ARM, ROHS COMPLIANT: NA
120621	
065145-Xd5	
210582	(PRICE/EA) CLD 980 PNEUMATIC MULTIPLIER (1 1/2 DR)
20342	
120375	
360125	(PRICE/EA) FLEXS-50SX AUTO SHUT-OFF PULSE TOOL (1/4 F/HEX)
20061	
120036	
77010	(PRICE/EA) BMX50F TORQUE SENSOR (5-50 LBF.FT) ARCII
06005b-109-Tb	
79002	LPX 40Z TORQUE SENSOR (4-40 OZF.IN) ARCII
020155cal	
77003	BMX10I TORQUE SENSOR (1-10 LBF.IN) ARCII
145712	
20561	
20101	
20573	
020452cal	
060095	WHEEL 2 (1/4 3/8 MALE SQ DRIVE)
Precaliso	
144383	(PRICE/EA) BL-5000X BRUSHLESS ELECTRIC DRIVER (1/4 F/HEX)
20491	
020442cal	
20504	TSN25A-PR CAM-OVER WRENCH WITH PUSH ROD (3/8 SQ DR.)
120033	

Item Ã 020314	
70022	
770055	
72606	(PRICE/EA) MOUNTING BRACKET (FOR LTT MODELS)
067999-B	
70800	(PRICE/EA) EZ-TORQ II 10I(TORQUE ANALYZER 1-10 LBF.IN)
360138	(PRICE/EA) FLEXS-50R AUTO SHUT-OFF RIGHT ANGLE PULSE TOOL (3/8 SQ. DR.)
145848nf450-Aesd	145848 NF450-A ESD
077001	BMX40Z TORQUE SENSOR (4-40 OZF.IN) ARCII
144380	(PRICE/EA) BL-5000 BRUSHLESS ELECTRIC DRIVER (4MM HIOS DR.)
20074	
70802	(PRICE/EA) EZ-TORQ II 100I(TORQUE ANALYZER 10-100 LBF.IN)
230583	
20494	
120167	
20-C12870	
20-D94406	
Cls2/100 Maschinen Koffer (Koruyucu Kab)	
20439	
068400	LTT10I TORQUE ANALYZER (1-10 LBF.IN)
077010	BMX50F TORQUE SENSOR (5-50 LBF.FT) ARCII
72005	
06002b-104	
120123	
20-D94402	
20443	
68108	
60091	(PRICE/EA) S-24 SEGMENT ARM (1/2 MALE SQ DR)
020067cald	

145665cald	
20123	ADS4S DIAL WRENCH WITH LIGHT SIGNAL (1/4 SQ DR.)
20446	
06005b-106-Tbcald	
144265	(PRICE/EA) CL-9000PS HT PUSH-TO-START ELECTRIC DRIVER (1/4 F/HEX)
06005b-106-Tbcal	
66100	
240190	TMS50 ELECTRONIC TORQUE SCREW DRIVER (1/4 SQ. DR.)
708003	
63293	
20569	
120186	
63971	
213014	(PRICE/EA) CLS 2/150 PNEUMATIC MULTIPLIER (1 DR)
145654	
120159	
145702	
145857	NF450P-A ESD PLUS BRUSHLESS DRIVER W/DOUBLE HIT SOFT START (1/4 F/HEX)
20557	
110107	DM 2000 CLICK WRENCH (1 SQ. DR.)
360322	
360019	(PRICE/EA) XP60A ANGLE AIR SCREW DRIVER (1/4 F/HEX)
Ltt100icald	(PRICE/EA) MOUNTZ 068403 (LTT100I) CALIBRATED
20178	ETX 100 WRENCH TRANSDUCER ARCII
20251	
20456	
145655	
77012	BMX250F TORQUE SENSOR (25-250 LBF.FT) ARCII
145865	(PRICE/EA) NFS150-A ESD SOFT STOP BRUSHLESS DRIVER W/SPEED CONTROL SOFT START (1/4 F/HEX) V3

120778	
120084	
120160	
40601	
240181	TMW 20A ELECTRONIC TORQUE ANGLE WRENCH (1/4 SQ. DR.)
63978	
145667	
020066caldu	
120143	
68405	LTT50F TORQUE ANALYZER (5-50 LBF.FT). WITH CALIBRATION
68195	
144430	
145846	(PRICE/EA) NF150-A ESDBRUSHLESS DRIVER W/SPEED CONTROL SOFT START (1/4 F/HEX) V3
240200	TMW 300A ELECTRONIC TORQUE ANGLE WRENCH (1/2 SQ. DR.)
230063	
20502	TSN55-PR CAM-OVER WRENCH WITH PUSH ROD (3/8 SQ DR.)
68113	
41cl4-0611	
20062	
067999-C	
020442caldu	
608036	
06002a-174-Tbcaldu	
41cl65-0490	
260212	EZ-30T APC POSI-CONTROL TELESCOPING ARM (MAX. REACH 37.5)
20374	
120166	
20590	

360126	(PRICE/EA) FLEXS-50S AUTO SHUT-OFF PULSE TOOL (3/8 SQ. DR.)
068402	LTT50I TORQUE ANALYZER (5-50 LBF.IN)
773820	
170231	(PRICE/EA) BLRTSX 100I-H BRUSHLESS ROTARY TRANSDUCER (10-100 LBF.IN) ARCII
077002	BMX80Z TORQUE SENSOR (8-80 OZF.IN) ARCII
703900	
120014	
20173	
22535	
170236	(PRICE/EA) BLRTSX 36F BRUSHLESS ROTARY TRANSDUCER (4-36 LBF.FT) ARCII
068401	LTT25I TORQUE ANALYZER (2.5-25 LBF.IN), ROHS COMPLIANT: NA
260083	(PRICE/EA) EZ-40R ARTICULATED TORQUE ARM
23027	
020067cal	
145790	SCOUT II (SCREW COUNTER)
360011	
701080	
260079	(PRICE/EA) EZ-40 LINEAR TORQUE ARM
68187	
77014	(PRICE/EA) BMX1000F TORQUE SENSOR (100-1000 LBF.FT) ARCII
60050	
213006	CLS 2/600 PNEUMATIC MULTIPLIER (1 1/2 DR)
68142	
60234	(PRICE/EA) RFS-200 (ROTARY CALIBRATION FIXTURE 1-200 LBF.IN)
144705	(PRICE/EA) HS-20 SCREW PRESENTER (MAX. M2.0)
20423	
240180	TMW 20 ELECTRONIC TORQUE WRENCH (1/4 SQ. DR.)

121477	
120261	
70007	
360300	
020079cald	
240201	TMW 1000A ELECTRONIC TORQUE ANGLE WRENCH (3/4 SQ. DR.)
63981	
Scout Ii	
272448	
79005	LPX 20I TORQUE SENSOR (2-20 LBF.IN) ARCII
771069	
68163	
360004	
213704	HG20 HAND MULTIPLIER (1 DR)
20065	
68167	
360009	
020074caldu	
120683	
070803	EZ-TORQ II 150I (TORQUE ANALYZER 15-150 LBF.IN)
068000-D	
20445	
120371	
70605	
72001	
145667cald	
020442cald	
20068	
020441cald	
20235	

077014	BMX1000F TORQUE SENSOR (100-1000 LBF.FT) ARCII
280024	
215027	
144266	(PRICE/EA) CLF-6500HH ROBOTIC DRIVER (4MM HIOS DR.)
360129	(PRICE/EA) FLEXS-70S AUTO SHUT-OFF PULSE TOOL (3/8 SQ. DR.)
60113	
020066cald	
60398	
144400	
145649	
68400	(PRICE/EA) LTT10I TORQUE ANALYZER (1-10 LBF.IN)
67071	RIGHT ANGLE ADAPTER (FOR EF080 EF120)
120079	
M50-Ultra	
360156	(PRICE/EA) FLEXS-80P AUTO SHUT-OFF PISTOL PULSE TOOL (3/8 SQ. DR.)
180503	
144385	BL-5000X ESD ELECTRIC DRIVER (1/4 F/HEX), ROHS COMPLIANT: NA
260078	(PRICE/EA) EZ-25 LINEAR TORQUE ARM
210318	EFCIP 70 PLUS ELECTRIC MULTIPLIER (1 1/2 DR)
145734caldu	BFT120 ESD BRUSHLESS DRIVER (1/4 F/HEX)
68148	
609000	
240198	TMW 340 ELECTRONIC TORQUE WRENCH (1/2 SQ. DR.)
020440cal	
120034	
20377	
61527	
145645	

14-3000238	
360139	(PRICE/EA) FLEXS-60R AUTO SHUT-OFF RIGHT ANGLE PULSE TOOL (3/8 SQ. DR.)
170202	(PRICE/EA) RTSX50I-H ROTARY TRANSDUCER (5-50 LBF.IN) ARCII
20612	
22620	
20611	
20290	
20484	
077011	BMX100F TORQUE SENSOR (10-100 LBF.FT) ARCII
72995	PTT-2000 TORQUE ANALYZER WITH BOLT AUDIT (FOR HSD)
20333	
120372	
20108	BDS80A DIAL WRENCH (3/8 SQ DR
20248	
170201	(PRICE/EA) RTSX10I ROTARY TRANSDUCER (1-10 LBF.IN) ARCII
125002	
608038	
60095	(PRICE/EA) WHEEL 2 (1/4 3/8 MALE SQ DRIVE)
145740/145741calibrated	MOUNTZ 145740 HDC40I W/ 145741 HD150-A CALIBRATED
61531	
077012	BMX250F TORQUE SENSOR (25-250 LBF.FT) ARCII
20401	
280010	
144332	
20384	
20185	
110100	
360030	
068001-C	

125005	
62032	RFS-500 (ROTARY CALIBRATION FIXTURE 5-500 LBF.FT)
120148	
360152	FLEXS-150P AUTO SHUT-OFF PISTOL PULSE TOOL (3/4 SQ. DR.)
170237	(PRICE/EA) BLRTSX 73F BRUSHLESS ROTARY TRANSDUCER (8-73 LBF.FT) ARCII
215028	
06005b-104-Tb	
144346	
145615	
20175	
99special	
68174	
213705	(PRICE/EA) HG30 HAND MULTIPLIER (1 1/2 DR)
145647	
180521	
068003-B	
070800	EZ-TORQ II 10I(TORQUE ANALYZER 1-10 LBF.IN)
145619	
120218	
20177	ETX 30 WRENCH TRANSDUCER ARCII
280013	
40424	
125000	
20589	
120352	
20102	
061429	LCU-2 (LUBRO CONTROL UNIT), ROHS COMPLIANT: NA
120116	
	(PRICE/EA) NF450P-A ESDBRUSHLESS DRIVER W/SPEED

145851	CONTROL SOFT START (1/4 F/HEX) V3
145848	(PRICE/EA) NF450-A ESD BRUSHLESS DRIVER W/SPEED CONTROL SOFT START (1/4 F/HEX) V3, ROHS COMPLIANT: NA
120709	
020593cald	
20449	
360320	
61399	
20575	STB35 CAM-OVER WRENCH (WITH PUSH ROD)
145830	BF120 ESD PLUS BRUSHLESS DRIVER W/DOUBLE HIT SOFT START (1/4 F/HEX)
145666	
110112	CCW (1 SQ. DR.)
20252	(PRICE/EA) TSN125 CAM-OVER WRENCH (1/2 SQ DR.)
Bmx-50i	
70019	
068003-C	
020252	TSN125 CAM-OVER WRENCH (1/2 SQ DR.)
124406	
20369	
077005	BMX50I TORQUE SENSOR (5-50 LBF.IN) ARCII
213002	CLS 2/100 PNEUMATIC MULTIPLIER (1 DR)
40052	
20448	
68126	
144351	(PRICE/EA) VZ-1820PS PUSH-TO-START ELECTRIC DRIVER 120V (1/4 F/HEX)
70020	
145651	
020082caldu	
120367	
170204	RTSX100I-H ROTARY TRANSDUCER (10-100 LBF.IN) ARCII

068002-B	
77005	(PRICE/EA) BMX50I TORQUE SENSOR (5-50 LBF.IN) ARCII
20403	
144771	FK-520RS SCREW PRESENTER
68141	
360037	
145734cal	BFT120 ESD BRUSHLESS DRIVER (1/4 F/HEX)
61625	
68404	(PRICE/EA) LTT250I TORQUE ANALYZER (25-250 LBF.IN)
40555	
708001	
260077	(PRICE/EA) EZ-12 LINEAR TORQUE ARM, ROHS COMPLIANT: NA
260155	(PRICE/EA) DPC-990 POSI-CONTROL SYSTEM
63973	
20620	
70803	(PRICE/EA) EZ-TORQ II 150I (TORQUE ANALYZER 15-150 LBF.IN)
360109	
020593caldu	
20549	
20188	
020314caldu	
20560	
077006	BMX100I TORQUE SENSOR (10-100 LBF.IN) ARCII
20082	
280010caldu	
360100	FLEXS-30PX AUTO SHUT-OFF PISTOL PULSE TOOL (1/4 F/HEX)
20182	
120719	
20452	

Wartungseinheit Kpl. (5 Kg)	
068001-B	
120058	
170206	(PRICE/EA) RTSX200I-H ROTARY TRANSDUCER (20-200 LBF.IN) ARCII
68106	
120370	
20299	
66118	
068403	LTT100I TORQUE ANALYZER (10-100 LBF.IN)
20508	
20004	(PRICE/EA) MTS 1200 DIAL TORQUE ANALYZER
120594	
360016	(PRICE/EA) XP40A ANGLE AIR SCREWDRIVER (1/4 F/HEX)
290121	
61429	(PRICE/EA) LCU-2 (LUBRO CONTROL UNIT), ROHS COMPLIANT: NA
144459	
63983	(PRICE/EA) RDA500F (50-500LBF.FT 3/4F X 3/4M)
145824	
Bmx-500f	
21-13561	
020452caldu	
72506	
213905	
180512	
40069	
144234	(PRICE/EA) SS4000X-ESD ELECTRIC DRIVER (1/4 F/HEX)
020003	MTS 400 DIAL TORQUE ANALYZER
011200a67840	
070801	EZ-TORQ II 50I(TORQUE ANALYZER 5-50 LBF.IN)

66106	
213898	DMA 10266 (1.5/148)
20100	Dial Torque Wrench, 7-35in/lbs. (0.8-4Nm), 1/4"Sq.Drive
360032	
61524	
61587	(PRICE/EA) WHEEL 1 (1/4 MALE SQ DRIVE)
701091	
144280	VB-1510 BRUSHLESS ELECTRIC DRIVER 120V (1/4 F/HEX)
145789	
144116	CL-6000 ELECTRIC DRIVER (1/4 F/HEX)
020004	MTS 1200 DIAL TORQUE ANALYZER
20626	
60064	WHEEL 4 (1/4 3/8 MALE SQ DRIVE)
20442	
068000-B	
Open-End Wrench 3/8 Inch (9,53 Mm)	
20464	
144752	
077013	BMX500F TORQUE SENSOR (50-500 LBF.FT) ARCII
068002-D	
20078	
68124	
68182	
077000	BMX20Z TORQUE SENSOR (2-20 OZF.IN) ARCII
78001	SDX50I SCREW DRIVER TRANSDUCER ARCII
Stc-30plus	
144098	(PRICE/EA) CL3000-ESD ELECTRIC DRIVER (4MM HIOS DR.)
145793	(PRICE/EA) BF080 ESD BRUSHLESS DRIVER W/SPEED CONTROL SOFT START (1/4 F/HEX) V3
145847	(PRICE/EA) NF220-A ESDBRUSHLESS DRIVER W/SPEED CONTROL SOFT START (1/4 F/HEX) V3

72997	Barcode Reader for PTT & LTT
68104	
020074cald	
067999-D	
Bmx-100i	
20186	
145875	(PRICE/EA) YF90N-A ESD BRUSHLESS ELECTRIC DRIVER (1/4 F/HEX)
77000	(PRICE/EA) BMX20Z TORQUE SENSOR (2-20 OZF.IN) ARCII
20563	
800-456-1828	
145684-C1	
63970	
20539	
020314cal	
20003	MTS 400 DIAL TORQUE ANALYZER
20595	MTBN200-PR BREAK-OVER WRENCH (WITH PUSH ROD)
145650	
170272	BLRTSX 73F-RA BRUSHLESS ROTARY ANGLE SHAFT TRANSDUCER ARCII
72999	(PRICE/EA) TORQUE RANGE N-M:-, TORQUE RANGE FT-LB:-, ACCURACY %:-, PRODUCT RANGE:-, ROHS COMPLIANT: NA
20249	
145774	
77015	BMX2500F TORQUE SENSOR (250-2500 LBF.FT) ARCII
Tsn25a	
120553	
360014	
63977	
240184	TMW100 ELECTRONIC TORQUE WRENCH (3/8 SQ. DR.)
120174	
20373	

20441	
360137	FLEX-70S NON SHUT-OFF PULSE TOOL (3/8 SQ. DR.)
072999	TORQUE RANGE N-M:-, TORQUE RANGE FT-LB:-, ACCURACY %:-, PRODUCT RANGE:-, ROHS COMPLIANT: NA
145776	(PRICE/EA) BF120 ESDBRUSHLESS DRIVER W/SPEED CONTROL SOFT START (1/4 F/HEX) V3
067999-A	
144104	(PRICE/EA) SS2000-ESD ELECTRIC DRIVER (4MM HIOS DR.)
068403cal	LTT100I TORQUE ANALYZER (10-100 LBF.IN)
145788	
68140	
M100	
20157	
360122	(PRICE/EA) FLEXS-30SX AUTO SHUT-OFF PULSE TOOL (1/4 F/HEX)
020315caldu	
020155cald	
06002c-108	
145845	BF045 ESD SOFT-STOP BRUSHLESS DRIVER (4MM HIOS DR.) V3
20550	
110110	DM 200 CLICK WRENCH (1/2 SQ. DR.)
20153	
20418	
68139	
210308	EFCIP 80 ELECTRIC MULTIPLIER (1 1/2 DR)
360001	
63302	LOADING BENCH LB250F
71023	SMX 50F SOCKET TRANSDUCER (5-50 LBF.FT) ARCII
145743	(PRICE/EA) HD220-A HYBRIDELECTRIC DRIVER (1/4 F/HEX)
20239	TSN25A CAM-OVER WRENCH (3/8 SQ DR -6MM HOLE SPINDLE DIA.)
20081	

61628	
Bmx-50f	
62128	BMX5000F)
20376	
360305	(PRICE/EA) FLEXC-8RX RIGHT ANGLE CORDLESS SCREWDRIVER (1/4 SQ. DR.)
068405	LTT50F TORQUE ANALYZER (5-50 LBF.FT)
20476	
145780	
144143	SB-650C AUTO REVERSING TAPPER ELECTRIC DRIVER
110103	DM 120 CLICK WRENCH (1/2 SQ.DR.)
77008	(PRICE/EA) BMX500I TORQUE SENSOR (50-500 LBF.IN) ARCII
40409	
68159	
360017	XP48A ANGLE AIR SCREW DRIVER (1/4 F/HEX)
70801	(PRICE/EA) EZ-TORQ II 50I(TORQUE ANALYZER 5-50 LBF.IN)
68136	
170200	(PRICE/EA) RTSX10I-H ROTARY TRANSDUCER (1-10 LBF.IN) ARCII
120374	
145836	(PRICE/EA) BFS080 ESD SOFT STOP PLUS BRUSHLESS DRIVER W/SPEED CONTROL SOFT START (1/4 F/HEX)
020452cald	
210578	(PRICE/EA) CLD 280 PNEUMATIC MULTIPLIER (1 DR)
20338	
020440caldu	
020440cald	
20000	MTP 10 DIAL TORQUE ANALYZER
20404	
120349	
61619	
280010cal	

20122	ADS40S DIAL WRENCH WITH LIGHT SIGNAL (3/8 SQ DR.)
20155	
Hdc40i	CONTROLLER
077016	BMX5000F TORQUE SENSOR (500-5000 LBF.FT) ARCII
40051	
077003	BMX10I TORQUE SENSOR (1-10 LBF.IN) ARCII
77016	(PRICE/EA) BMX5000F TORQUE SENSOR (500-5000 LBF.FT) ARCII
22560	
145673	
290123	
120142	
68107	
360008	
360005	
280023	
060234	RFS-200 (ROTARY CALIBRATION FIXTURE 1-200 LBF.IN)
68406	(PRICE/EA) LTT100F TORQUE ANALYZER (10-100 LBF.FT)
145661	
020245	PIN RETENTION (1/2 SQ DR.)
145600	
121017	
240202	TMW 1000 ELECTRONIC TORQUE WRENCH (3/4 SQ. DR.)
145877	(PRICE/EA) YFC-35D CONTROLLER
72004	
213008	CLS 2/800 PNEUMATIC MULTIPLIER (1 1/2 DR)
66116	
144457	
20104	
145662	
144126/145683calibrated	144126/145683 CALIBRATED

145903	
145740	(PRICE/EA) HDC40I HYBRID CONTROLLER
20151	
068406	LTT100F TORQUE ANALYZER (10-100 LBF.FT)
126053	
260157	(PRICE/EA) EZ-40RPC POSI-CONTROL ARTICULATED TORQUE ARM
120225	
20119	(PRICE/EA) DDS800S DIAL WRENCH WITH LIGHT SIGNAL (3/4 SQ DR.)
66101	
062128	BMX5000F)
70610	
020067caldu	
20628	
20458	
M-100	100 lbf-in., 0 to 1130 cN-m
360003	
240182	TMW50 ELECTRONIC TORQUE WRENCH (3/8 SQ. DR.)
120080	
210580	
145745	(PRICE/EA) HD450-A HYBRID ELECTRIC DRIVER (1/4 F/HEX)
144709	HS-50 SCREW PRESENTER (MAX. M5.0)
21-13569	
068003-D	
020441cal	
20409	
Tsn55	
144126	CL-7000X ELECTRIC DRIVER (1/4 F/HEX)
20159	STB70 CAM-OVER WRENCH (16MM SPIGOT)
210581	CLD 780 PNEUMATIC MULTIPLIER (1 1/2 DR)

20240	
68144	
77013	
20340	
360124	(PRICE/EA) FLEXS-40S AUTO SHUT-OFF PULSE TOOL (3/8 SQ. DR.)
020240	6MM HOLE SPINDLE DIA.)
063302	LOADING BENCH LB250F
69008	
120170	
260164	
68401	(PRICE/EA) LTT25I TORQUE ANALYZER (2.5-25 LBF.IN), ROHS COMPLIANT: NA
20586	
145653	
020315cal	
06002c-108-Tb	
Scout Ii Screw Counter	
070802	EZ-TORQ II 100I(TORQUE ANALYZER 10-100 LBF.IN)
20419	
66109	
068404	LTT250I TORQUE ANALYZER (25-250 LBF.IN)
62508	SDX10I TORQUE SENSOR ARCII
Cls2/100	
23024	
20341	
120215	
145675	
145684	
20444	
77011	(PRICE/EA) BMX100F TORQUE SENSOR (10-100 LBF.FT) ARCII

20395 077008	BMX500I TORQUE SENSOR (50-500 LBF.IN) ARCII
62109	
41cl65-0500	
360155	(PRICE/EA) FLEXS-70P AUTO SHUT-OFF PISTOL PULSE TOOL (3/8 SQ. DR.), ROHS COMPLIANT: NA
068001-D	
360103	(PRICE/EA) FLEXS-50PX AUTO SHUT-OFF PISTOL PULSE TOOL (1/4 F/HEX)
64000	
360013	
360106	(PRICE/EA) FLEXS-60P AUTO SHUT-OFF PISTOL PULSE TOOL (3/8 SQ. DR.)
060054	S-48 SEGMENT ARM (1 MALE SQ DR)
06002a-174-Tbcal	
72608	
144124	A6500X ELECTRIC DRIVER (1/4 F/HEX)
77002	(PRICE/EA) BMX80Z TORQUE SENSOR (8-80 OZF.IN) ARCII
360102	FLEXS-40P AUTO SHUT-OFF PISTOL PULSE TOOL (3/8 SQ. DR.)
280012	
068403caldu	LTT100I TORQUE ANALYZER (10-100 LBF.IN)
144323	
600021	
077004	BMX25I TORQUE SENSOR (2.5-25 LBF.IN) ARCII
360310	FLEXC II-3PX PISTOL BRUSHLESS CORDLESS SCREW DRIVER (1/4 F/HEX)
120110	
280015	(PRICE/EA) TITAN 600F CLICK WRENCH (3/4 SQ. DR.)
210571	(PRICE/EA) CLD 225 PNEUMATIC MULTIPLIER (1 DR)
120623	
180504	
72998	Multiplexer for PTT & LTT

20337	
120044	
20156	
145706	
061587	WHEEL 1 (1/4 MALE SQ DRIVE)
120130	
145854	(PRICE/EA) NF450-A ESD PLUS BRUSHLESS DRIVER W/DOUBLE HIT SOFT START (1/4 F/HEX)
020500	TSN25D-PR CAM-OVER WRENCH WITH PUSH ROD (1/4 SQ DR.)
22355	
144111	
120470	
020441caldu	
Ltt-2100	
68111	
68120	
06005b-103	
145834	(PRICE/EA) BFS120 ESD SOFT STOP BRUSHLESS DRIVER W/SPEED CONTROL SOFT START (1/4 F/HEX) V3
020593cal	
145683	
145611	
360301	
125004	
120815	
077007	BMX250I TORQUE SENSOR (25-250 LBF.IN) ARCII
020155caldu	
180516	
068004-B	
20-B25900	
20454	

608032	
65145	
260158	EZ-100RPC POSI-CONTROL ARTICULATED TORQUE ARM
020082cald	
771050	
145773	
63972	
Item Ã 022035	
20498	
360326	
280022	
67067	RIGHT ANGLE ADAPTER (FOR DLV 7100 7200 SERIES)
144327	
68402	(PRICE/EA) LTT50I TORQUE ANALYZER (5-50 LBF.IN)
360010	
360006	
120003	
144378	(PRICE/EA) VZ-4506 ELECTRIC DRIVER 120V (1/4 F/HEX)
Hg40	
68403	(PRICE/EA) LTT100I TORQUE ANALYZER (10-100 LBF.IN)
360162	FLEXS-70RG AUTO SHUT-OFF RIGHT ANGLE PULSE TOOL (3/8 SQ. DR.)
20125	ADS12AS DIAL WRENCH WITH LIGHT SIGNAL (3/8 SQ DR.)
120082	
60012	
060091	S-24 SEGMENT ARM (1/2 MALE SQ DR)
68122	
20245	PIN RETENTION (1/2 SQ DR.)
360154	(PRICE/EA) FLEXS-65P AUTO SHUT-OFF PISTOL PULSE TOOLS (3/8 SQ DR.)
81-1049	(PRICE/EA) TSN125 CAM-OVER WRENCH W/PROTECTIVE COVER AND HANGING LOOP

20500	(PRICE/EA) TSN25D-PR CAM-OVER WRENCH WITH PUSH ROD (1/4 SQ DR.)
22025	
20066	
20187	
68165	
148270	
020068cald	
260152	
20402	
063983	RDA500F (50-500LBF.FT 3/4F X 3/4M)
771049	
144121	(PRICE/EA) CL-6500 ELECTRIC DRIVER (1/4 F/HEX)
360012	
260163	
144103	
120035	
020074cal	
20629	
170238	(PRICE/EA) BLRTSX 118F BRUSHLESS ROTARY TRANSDUCER (12-118 LBF.FT) ARCII
145710	
144276	
60054	(PRICE/EA) S-48 SEGMENT ARM (1 MALE SQ DR)
144117	(PRICE/EA) CL-6500 ELECTRIC DRIVER (4MM HIOS DR.)
145665	