


Wohner

Garanti: 12 ay
Bu ürüne ait Türkiye içi kapı teslim fiyat ve teslim süresi içeren teklifimizi almak için **info@yursat.com.tr** e-posta adresine başvuru yapılabilir ya da ayrıntılı bilgi için +90 224 240 03 04 numaralı telefonumuzdan bizlere ulaşabilirsiniz.
Wohner Markası, tedarik süresi için lütfen bizimle iletişime geçiniz.

Firmamız Wohner Türkiye Distribütörü veya temsilcisi değildir. Firmamız sipariş durumunda, belirtilen ürünlerde sadece Orjinal ve yeni ürün teklifi sunmaktadır. Bu sitede gösterilen Özel marka adları ve ticari markalar ilgili sahiplerinin mülkiyetindedir, talep durumunda kaldırılmaktadır.



Ürün	Açıklama
32430 Bara Adap.3f 25a	
32454 Bara Adapt.3f 63a 54mm	
01563 / 80a	
1495	
1563	80A
1240	300A
1243	440A
32439	Anschlussadapter 25 A 45 x 260 Doppelschiene
32472	Anschlussadapter 80 A 54 x 260 Doppelschiene
32456	Anschlussadapter 63 A 63 x 200 Monorail
1245	
W 32486	BUS ADAPTER 32 A (32486) Single Adjustable Mounting with Terminals Rail 45x200

01601	Busbar support PE/N 1-pole, individually mountable ; Dimensions [mm]: 20x49.5x65 (WxDxH); PU is:1;
01245	busbar cover - for busbar 12-30x10 - 1m long
32156	Busbar adapter 250 A, 3-pole, adapted on switching devices for Schneider Electric NSX100- NSX250, GV7, J250 105x190, connect to system top / bottom; Dimensions [mm]:105x35x190 (WxDxH); PU is:1;
32430	Busbar adapter 25 A 1 sliding Mounting rail 45 x 200, with cables AWG 12 (4th mm ²); Dimensions [mm]:45x63x200 (WxDxH); PU is:4
31158	Secur Powerliner - Reiter-Lasttrennschalter mit Sicherungen - 3-polig, 3-polig schaltend - für D1- und D2-Sicherungen - 63A / 400V AC
31574	Secur EasyLiner - Reiter-Lasttrennschalter mit Sicherungen - 3-polig, 3-polig schaltend - für D01- und D02-Sicherungen - 63A / 400V AC
33732	terminal compartment cover - for 33 700, 33 770, 33 720, 33 771, 33 715, 33 772 - Size: Size 00, high version
33737--un	clamping bracket - for QUADRON®185Power - Size: Size 00
37217	Current transformer 800 A / 5 A - 2.5VA / Class 1 - When used on busbars or in adapters 630 A additionally 37900 necessary.
37900	Fastening clip for current transformer - for fixing on busbars and in adapters 630 A
37220	Current transformer 250 A / 5 A - 2.5VA / Class 0.5 - When used on busbars or in adapters 630 A additionally 37900 necessary.
33751	current transformer 150 A / 5 A, - 2.5VA / Class 0.5 - Size: Size 00
01625	Busbar E-Cu -tinned, length 2.40m, 30x10, Rated current 630 A
01356	PE/N busbar support - 2-pole, individually mountable - suitable for busbars 12-30x5/10
01430	Universal busbar support 185power
01431	Rail support cover set - 1x left, 1x right
01432	center cover for Rail support 01430 - when using the carrier as center beam
01434	System cover on the front - 100mm
01438	Connection strip for 185 mm system - 3-pin, screw connection - for 2 cable lugs 240mm ² - 800A - for round and flat conductors

32741	Busbar adapter 630 A - 185 Power System - universal version up to 630A, Phase pitch 43-46mm - Connection above, CrossLink- Terminal contacting - Size: 150x585x35,
01495	Universal busbar support with internal screw holes - 3-pole, suitable for busbars 12, 15, 20, 25, 30, x5 - 10
01573	end cover - to cover the busbar ends, - suitable for No.: 01495 and 01500, - is attached to the busbar support cover infected
01199	terminal board - for 12x5-30x10 & double T & triple T profile - 3-pin, with cover cap - Connection: round conductor 95-185mm ² , - can be used up to max. 460A - Dimensions WxH: 135x200 mm
33601 250A	
31158	Secur Powerliner - Rider switch disconnecter with Fuses - 3-pole, 3-pole switching - for D1 and D2 fuses - 63A / 400V AC
32430	Busbar adapter 25 A 1 movable DIN rail 45 x 200, with cables AWG 12 (4 mm ²); Dimensions [mm]:45x63x200 (WxDxH); PU is:4;detailed product data
32430	Busbar adapter 25 A 1 movable DIN rail 45 x 200, with cables AWG 12 (4 mm ²); Dimensions [mm]:45x63x200 (WxDxH);
33601	NH fuse switch disconnecter size 1, 250 A, Rider, bottom/top connection with M10 screw CrossLink® Technology; Dimensions [mm]:184x129x243 (WxDxH);
32430	Busbar adapter 25 A 1 movable DIN rail 45 x 200, with cables AWG 12 (4 mm ²); Dimensions [mm]:45x63x200 (WxDxH); PU is:4
33199	
1678	
31368	
33246	
1927	
31100	
3525	
Lts-3, 630a	
33317	
35016	
1670	
33933	

33203
31976
36220
33439
31941
33600
1059
32632
33153
01583
1135
32766
31308
1258
31235
33403
1129
35017
32-461
31208
3221
Lts-00
31191
5784
31028
31578
1495
33773
31543
33457
1070

[33505](#)[31029](#)[33726](#)[31924](#)[1935](#)[31388](#)[32907](#)[32984](#)[33717](#)[31194](#)[1145](#)[33151](#)[5800](#)[1274](#)[1694](#)[31351](#)[33938](#)[33036](#)[3910](#)[3913](#)[32921](#)[3384](#)[1359](#)[32785](#)[33366](#)[31117](#)[32575](#)[31973](#)[31281](#)[32374](#)

[32755](#)[31122](#)[32444](#)[33502](#)[32607](#)[33449](#)[33308](#)[3502](#)[33435](#)[01518](#)[31567](#)[3217](#)[33973](#)[33917](#)[3351](#)[32914](#)[3575](#)[31925](#)[33351](#)[33219](#)[31579](#)[1990](#)[31118](#)[01508000a](#)[32937](#)[31299](#)[3213](#)[3917](#)[31950](#)[33-306](#)

31
3759
33929
36103
1484
1586
1132
32978
Nh3-3p-630a/690v
33-307
31934
32452
Wo01990
33464
1724
1687
31559
32601
33454
33346
1704
33451
33159
32511
33945
32402
3568
3757
33447
31939.01
33341

31572	
31914	Seitenmodul - für 31 574 und 31 575
36903	
31961	
33198	
1729	
1103	
1380	
31203	
33702	
1562	
Spl D0 Ac22	INSURANCE ADAPTER
32214	
1185	
33947	
33222	
31204	
33444	
1116	
31935	
Us31357	
31482	
1911	
1596	
3765	
3915	
8824	
35001	
78139	
31297000	

1722
3582
78105
3570
3577
31570
1688
32-159
32915
3916
5801
3197
36100
33294
01539
33516
1424
33168
1601
31355
1355
33720
1369
31407
32974
489
32651
32637
33433
1512
33167

31901	
1026	
32448	
33746	
31544	
1587	
31910	
31364	
3300	
1518000	
31229	
3238	
33441	
1401	
31251	
1709	
31385	
32446	
1202	
33285	
3620	
3912	
03948	FUSE BASE 160AMP 3POLE 690V NH00 BUS-MOUNTING
32633	
31908	
31918	
33461	
33432	
2700430960	
31390	

1716
01573
32004
Pact Mcr-V2-6015-85 Fuse
3240
32018
33327
31215
1138
3654
31333
33740
31371
31525
1427
1538
1092
32431
33749
32609
3195
33437
31250
32425
1715
31349
Lts-3
1245
331980000
33946
33470

[3767](#)[33425](#)[32469](#)[78443](#)[33774](#)[1436](#)[Us01243](#)[33971](#)[36108](#)[33360](#)[33347](#)[1934](#)[32640](#)[1348](#)[31199](#)[31360](#)[36105](#)[1725](#)[5782](#)[01622](#)[32439](#)[33430](#)[32655](#)[1357](#)[36102](#)[31358](#)[1760](#)[31956](#)[32756](#)[31246](#)

1625000	
33738	clamping bracket - for QUADRAON®185Power - Size: Size 1 - 3
1590	
32976	
36107	
1285	
1703	
33155	
33704	
1230	
1429	
79811	
1287	
33939	
33936	
D02-16a	
31911	
1193	
3524	
31158	
31515	
33452	
31406	
32590	
33331	
33292	
31396	
31970	
33912	
33715	

1364	
1555	
31366	
32581	
33163	
1120	
31361	
33735	
1413	
33338	
31547	
30894	
1426	
3762	
3942	
33161	
1363	
32757	
3215	
21-0157	
1907	
32661	
33257	
31564	
33283	
31563	80A
32956	
31968	
33700	NH in-line fuse switch disconnecter 160 A - M8 screw, 3-pole switchable - Size: Size 00
33462	

33350
1756
32-061.000
5780
33745
1929
33208
33377
31237
33511
32513
31267
33922
1047
33724
31971
1543
33408
33142
33450
32983
5787
31225
32449
31219
32778
1128
33113
32455
33466
31303

31247
1251
31511
1547
3219
1675
33924
1228
33424
31955
1094
31284
32400
1718
3233
33272
1360
1199
1998
1218
31282
33974
1240
31296
1886
31313
31915
32215
6016
3561

3228
6025
31232
33926
01537
33510
33079
6080
31338
3587
32456
31512
32535
1430
1207
33928
31268
31-174
33162
Hb32963
31132
32662
3531
31005
1602
33194
3553
33334
31200
35005
31011

33393	
32466	
32-221	
31929000	
1356	
1127	
31-175	
33149	
5792	
31902	
33207	
33733	terminal compartment cover - Size: Size 1-3
3193	
31110	
01361	
1144	
35004	
31291	
32477	
33442	
1371	
31004	
1673	
31274	
31552	
1295	
31903	
33753	
3569	
33315	

31202
31293
31964
1162
32-430
33909
3914
32471
32768
31909
33460
33204
32987
32585
1748
31217
32775
31374
3225
32579
33324
3794
1275
31244
32951
1243
1730
33456
33385
31102
1318

32660
31943
3919
32782
31280
1069
5781
1362
33927
33217
31195
31228
1827
1433
30322
33921
33143
33126
33550
1742
33330
31442
01025
5783
3572
1136
31027
01-098
1597
31026

[33911](#)[33736](#)[31905](#)[3222](#)[3929](#)[33734](#)[33150](#)[33201](#)[1563](#)[30473](#)[33703](#)[1444](#)[1257](#)[33223](#)[1741](#)[1374](#)[3557](#)[1421](#)[1550](#)[33545](#)[1482](#)[1325](#)[1542](#)[33235](#)[32592](#)[78447](#)[33384](#)[31209](#)[31024](#)[31323](#)

31226
32156
3231
32973
01141
31133
1068
32975
36909
1719
1753
3768
33906
3793
32580
3550
33234
31278
33908
33931
1119
31370
33206
32758
33349
33398
31441
33540
31243
1932
31148

31241	
1139	
32457	
01508	
Eec 32 A, 2	Adapter EEC 32 A, 2 Adjustable Mounting Rails EEC 32 A, 2
1690	
01203	
33373	
1693	
6063	
36114	
5788	
31192	
31325	
33972	
01026	
33748	
33552	
32641	
33440	
6032	
33365	
31561	
4025	
32-460	
1121	
31072	
31073	
3552	
31929	

[31140](#)[31123](#)[1489](#)[32549000](#)[31314](#)[33445](#)[3290](#)[Lts-000](#)[33943](#)[32964](#)[33418](#)[32472](#)[32982](#)[31922](#)[1544](#)[525](#)[32-159.000](#)[33051](#)[32595](#)[33152](#)[31398](#)[3792](#)[33280](#)[33428](#)[1754](#)[31554](#)[32440](#)[1238](#)[1728](#)[31221](#)

31946
36109
33173
32438
1100
31972
33164
32465
1823
32441
1292
33718
1071
3226
1518
1440
3527
1008
3359
33361
33513
32072
31193
35007
01289
78893
5789
33555
33356
33343
Aes10*38 Fuse

33419
1689
1420
32610
31070
32420
33458
33742
33944
31399
33325
3234
3558
33507
1361
1996
3224
31039
1702
1147
33316
31173
31010
36902
33434
32140
1749
31227
31017
1573000

33602	
31086	
1676	
32582	
1540	
33467	
32570	
31211	
31974	
3930	
33913	
79859	
32426	
33446	
31386	
32023	
32763	
3239	
32168	
3301	
33363	
1573	
32408	
31157	
31275	
8825	
32594	
31372	
36112	
3316	
33701	NH in-line fuse switch disconnecter 250 A - M12 screw, 3-pin

switchable - Size: Size 1
33732
3299
31182
3173
1541
01625
1701
1025
1759
32486
33544
76490
1647
32963
31216
3574
31302
32001
31514
33394
33362
1236
3766
1890
31345
33455
33180
31939
1671
1203

33-200
31085
33193
31963
33775
33603
31394
33541
1936
36219
31184
1222
36912
3181
1165
33225
Vde-0660
31189
3370
1417
31238
31252
33770
33463
3795
1367
33216
1284
32584
31057